# AUD-DTE-2X2XLR Q-SYS Plugin Guide

For Q-SYS Designer · Plugin version 1.0.5

**The KanexPro AUD-DTE-2X2XLR plugin lets a Q-SYS system control the AUD-DTE-2X2XLR over the network.** It talks to the unit's own control port (TCP 8000): no other KanexPro software and no RS-232 cable are needed. Every control has a pin, so it can be wired to UCI buttons, logic and scripts like any Q-SYS control, and the plugin reads the unit back so changes made on its front panel, remote or web page show in Q-SYS.

> **Before you start —** the Q-SYS Core must reach the AUD-DTE-2X2XLR on TCP port 8000. Give the unit a fixed IP address (or a DHCP reservation).

## TABLE OF CONTENTS

1. What the plugin does
2. Before you start
3. Install the plugin
4. Properties
5. The plugin in Q-SYS Designer
6. Controls
7. Status
8. Troubleshooting

## 1. WHAT THE PLUGIN DOES

It controls: gain (dB), mute, delay (ms), output level, sensitivity, volume, EQ on, clear the EQ, expander on, clear the expander, limiter on, clear the limiter, presets, save, clear a preset, standby after no sound (min, 0 = never), standby kind, power.

Settings that only the unit's own web page has (its network, logins and firmware) stay on that page.

## 2. BEFORE YOU START

- ✓ Q-SYS Designer on a Windows computer, and a Q-SYS Core.
- ✓ The AUD-DTE-2X2XLR on the same network as the Core, or routed to it, with TCP port 8000 open between them.
- ✓ The unit's IP address (front panel or its own web page).

## 3. INSTALL THE PLUGIN

1. Download **KanexPro-AUD-DTE-2X2XLR-QSYS-1.0.5.zip** from the AUD-DTE-2X2XLR page on kanexpro.com (Resources) and unzip it.
2. Copy `KanexPro-AUD-DTE-2X2XLR.qplug` into `Documents\QSC\Q-Sys Designer\Plugins` on the Q-SYS Designer computer, or drag the file onto Designer's window.
3. Restart Q-SYS Designer. The plugin appears in Schematic Elements under **Plugins > KanexPro**.
4. Drag it into the design, select it and set its properties (section 4).
5. Save the design to the Core and run it. The plugin connects by itself and shows its state on its Status control.

> **One plugin per unit —** for two AUD-DTE-2X2XLR units, add the plugin twice and give each its own IP address.

## 4. PROPERTIES

| PLUGIN PROPERTIES | |
|---|---|
| **IP Address** | The AUD-DTE-2X2XLR's address on the control network. Empty by default. |
| **Port** | 8000 (TCP), the unit's control port. Change it only if the unit's own web page was set to another port. |
| **Poll Interval** | How often, in seconds, the plugin reads the unit back. Default 10; 0 reads it only after a change from Q-SYS. |

## 5. THE PLUGIN IN Q-SYS DESIGNER




The AUD-DTE-2X2XLR plugin's control panel in Q-SYS Designer

## 6. CONTROLS

69 controls. Where a control is repeated for each input or output, it is listed once.

| # | Control | Where | What it does |
|---|---|---|---|
| 0 | **Status** | the plugin | Shows whether the plugin is connected to the unit, and why not (section 7). |
| 1 | **Gain (dB)** | each output | Sets the gain (dB) on each output, from -60 to 12. This model's output level in dB; it has no separate volume. |
| 2 | **Mute** | each output | Turns the mute on or off on each output. |
| 3 | **Delay (ms)** | each output | Sets the delay (ms) on each output. Choices: 0; 1; 2; 3; 4, and 36 more. |
| 4 | **Output level** | each output | Sets the output level on each output. Choices: +20 dBu; +14 dBu; +4 dBu; 0 dBV; -18 dBV. |
| 5 | **Gain (dB)** | each input | Sets the gain (dB) on each input, from -60 to 12. |
| 6 | **Mute** | each input | Turns the mute on or off on each input. |
| 7 | **Sensitivity** | each input | Sets the sensitivity on each input. Choices: +24 dBu; +14 dBu; +4 dBu; 0 dBV; -18 dBV, and 1 more. |
| 8 | **Delay (ms)** | each input | Sets the delay (ms) on each input. Choices: 0; 1; 2; 3; 4, and 36 more. |
| 9 | **Volume** | each dca | Sets the volume on each dca, from 0 to 100. |
| 10 | **Mute** | each dca | Turns the mute on or off on each dca. |
| 11 | **EQ on** | each output | Turns the EQ on on or off on each output. |

| | | | |
|---|---|---|---|
| 12 | **Clear the EQ** | buttons 1 to 2 | Clears that preset. |
| 13 | **EQ on** | each input | Turns the EQ on on or off on each input. |
| 14 | **Clear the EQ** | buttons 1 to 2 | Clears that preset. |
| 15 | **Expander on** | each input | Turns the expander on on or off on each input. |
| 16 | **Clear the expander** | buttons 1 to 2 | Clears that preset. |
| 17 | **Limiter on** | each output | Turns the limiter on on or off on each output. |
| 18 | **Clear the limiter** | buttons 1 to 2 | Clears that preset. |
| 19 | **Presets** | buttons 1 to 8 | Recalls that preset. |
| 20 | **Save** | buttons 1 to 8 | Saves the unit's current settings as that preset. |
| 21 | **Clear a preset** | buttons 1 to 8 | Clears that preset. |
| 22 | **Standby after no sound (min, 0 = never)** | the unit | Sets the standby after no sound (min, 0 = never), from 0 to 100. |
| 23 | **Standby kind** | the unit | Sets the standby kind. Choices: Standby; Sleep. |
| 24 | **Power** | buttons 1 to 2 | On: turns the unit on. Standby: puts the unit in standby. |

## 7. STATUS

| STATUS CONTROL | |
|---|---|
| **OK (green)** | Connected to the unit and reading it back. |
| **Initializing (blue)** | Connecting. It tries again every few seconds by itself. |
| **Fault (red)** | Not connected, with the reason: the unit does not answer, or the connection was refused or closed. |
| **Compromised (orange)** | Connected, but the unit refused the last change. The text names it. The control returns to what the unit reports at the next read. |
| **Not Present (grey)** | No IP address is set in the plugin's properties. |

## 8. TROUBLESHOOTING

**The Status control shows Fault and it does not connect.**
Check the IP address: find the unit's address on its front panel or its own web page and compare it with the plugin's IP Address property. A unit on DHCP may have moved; give it a fixed address or a DHCP reservation.

**The address is right, but it still does not connect.**
Check the network path. The Core and the unit must reach each other: the same network or VLAN, or a route between them. From a computer on the Core's network, the unit's web page should open at its address.

**Could a firewall be blocking it?**
Yes. A firewall or switch ACL between the Core and the unit must allow TCP port 8000 to the unit. Also leave the Port property at 8000 unless the unit's own web page was set to another port.

**It connects, but a change does not happen.**
The Status control shows Compromised and names the command the unit refused. The unit may be in standby: turn it on first.

**Changes made on the unit do not show in Q-SYS.**
Set Poll Interval above 0. Changes made on the unit's front panel, remote or web page then show within that many seconds.