AUD-DTE-70AMP Tesira Command Sheet

For Tesira Command String blocks · Version 1.0.2

Every command the AUD-DTE-70AMP takes over the network, as fixed strings for Tesira Command String blocks. The unit is controlled on its own control port (TCP 8000); no other KanexPro software is needed. The same strings, with their bytes, are in `KanexPro-AUD-DTE-70AMP-Tesira-Command-Sheet-1.0.2.csv` for copying.

> **Before you start —** the Tesira server must reach the AUD-DTE-70AMP on TCP port 8000. Give the unit a fixed IP address (or a DHCP reservation).

TABLE OF CONTENTS

1. Connection
2. Using the strings
3. Commands
4. Reading the unit back
5. Troubleshooting

1. CONNECTION

HOW THE UNIT IS CONTROLLED	
Transport	TCP, port 8000 (the unit's control port)
Line ending	CR LF (hex `0D 0A`), after every string
Pacing	One string at a time. The unit answers within about 1.5 s; wait for the answer before the next string.
A refused string	The unit answers with an error line.

2. USING THE STRINGS

1. Point the Command String block at the unit's IP address, TCP port 8000.
2. Add one command per row of section 3: its string, then the line ending (hex `0D 0A`).
3. Wire each command to the control that should send it. The Bytes column is the whole string as it goes on the wire, to compare with a network capture.

Settings that only the unit's own web page has (its network, logins and firmware) stay on that page.

3. COMMANDS

567 strings, and a template for each level with more values than fit a list.

#	Command	String	Bytes (hex, with the line ending)
1	**Sound: Volume = {level} (0 to 100)**	`set master vol {level}`	`the level in place of {level}`
2	**Sound: Volume = 0**	`set master vol 0`	`73 65 74 20 6D 61 73 74 65 72 20 76 6F 6C 20 30 0D 0A`
3	**Sound: Volume = 50**	`set master vol 50`	`73 65 74 20 6D 61 73 74 65 72 20 76 6F 6C 20 35 30 0D 0A`
4	**Sound: Volume = 100**	`set master vol 100`	`73 65 74 20 6D 61 73 74 65 72 20 76 6F 6C 20 31 30 30 0D 0A`
5	**Sound: Mute everything on**	`set master mute on`	`73 65 74 20 6D 61 73 74 65 72 20 6D 75 74 65 20 6F 6E 0D 0A`
6	**Sound: Mute everything off**	`set master mute off`	`73 65 74 20 6D 61 73 74 65 72 20 6D 75 74 65 20 6F 66 66 0D 0A`

7	Route: Dante out 1: Source = Dante in 1	`set output 1 from 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 6F 6D 20 31 0D 0A`
8	Route: Dante out 1: Source = Dante in 2	`set output 1 from 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 6F 6D 20 32 0D 0A`
9	Route: Dante out 1: Source = Mic/line in 1	`set output 1 from 3`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 6F 6D 20 33 0D 0A`
10	Route: Dante out 1: Source = Mic/line in 2	`set output 1 from 4`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 6F 6D 20 34 0D 0A`
11	Route: Dante out 1: Source = Mixer 1	`set output 1 from 5`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 6F 6D 20 35 0D 0A`
12	Route: Dante out 1: Source = Mixer 2	`set output 1 from 6`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 6F 6D 20 36 0D 0A`
13	Route: Dante out 2: Source = Dante in 1	`set output 2 from 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 6F 6D 20 31 0D 0A`
14	Route: Dante out 2: Source = Dante in 2	`set output 2 from 2`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 6F 6D 20 32 0D 0A`
15	Route: Dante out 2: Source = Mic/line in 1	`set output 2 from 3`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 6F 6D 20 33 0D 0A`
16	Route: Dante out 2: Source = Mic/line in 2	`set output 2 from 4`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 6F 6D 20 34 0D 0A`
17	Route: Dante out 2: Source = Mixer 1	`set output 2 from 5`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 6F 6D 20 35 0D 0A`
18	Route: Dante out 2: Source = Mixer 2	`set output 2 from 6`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 6F 6D 20 36 0D 0A`
19	Route: Line out 1: Source = Dante in 1	`set output 3 from 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 6F 6D 20 31 0D 0A`
20	Route: Line out 1: Source = Dante in 2	`set output 3 from 2`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 6F 6D 20 32 0D 0A`
21	Route: Line out 1: Source = Mic/line in 1	`set output 3 from 3`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 6F 6D 20 33 0D 0A`
22	Route: Line out 1: Source = Mic/line in 2	`set output 3 from 4`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 6F 6D 20 34 0D 0A`
23	Route: Line out 1: Source = Mixer 1	`set output 3 from 5`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 6F 6D 20 35 0D 0A`
24	Route: Line out 1: Source = Mixer 2	`set output 3 from 6`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 6F 6D 20 36 0D 0A`
25	Route: Line out 2: Source = Dante in 1	`set output 4 from 1`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 66 72 6F 6D 20 31 0D 0A`
26	Route: Line out 2: Source = Dante in 2	`set output 4 from 2`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 66 72 6F 6D 20 32 0D 0A`
27	Route: Line out 2: Source = Mic/line in 1	`set output 4 from 3`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 66 72 6F 6D 20 33 0D 0A`
28	Route: Line out 2: Source = Mic/line in 2	`set output 4 from 4`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 66 72 6F 6D 20 34 0D 0A`
29	Route: Line out 2: Source = Mixer 1	`set output 4 from 5`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 66 72 6F 6D 20 35 0D 0A`
30	Route: Line out 2: Source = Mixer 2	`set output 4 from 6`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 66 72 6F 6D 20 36 0D 0A`

31	Route: Speaker out 1: Source = Dante in 1	`set output 5 from 1`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 66 72 6F 6D 20 31 0D 0A`
32	Route: Speaker out 1: Source = Dante in 2	`set output 5 from 2`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 66 72 6F 6D 20 32 0D 0A`
33	Route: Speaker out 1: Source = Mic/line in 1	`set output 5 from 3`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 66 72 6F 6D 20 33 0D 0A`
34	Route: Speaker out 1: Source = Mic/line in 2	`set output 5 from 4`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 66 72 6F 6D 20 34 0D 0A`
35	Route: Speaker out 1: Source = Mixer 1	`set output 5 from 5`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 66 72 6F 6D 20 35 0D 0A`
36	Route: Speaker out 1: Source = Mixer 2	`set output 5 from 6`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 66 72 6F 6D 20 36 0D 0A`
37	Route: Speaker out 2: Source = Dante in 1	`set output 6 from 1`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 66 72 6F 6D 20 31 0D 0A`
38	Route: Speaker out 2: Source = Dante in 2	`set output 6 from 2`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 66 72 6F 6D 20 32 0D 0A`
39	Route: Speaker out 2: Source = Mic/line in 1	`set output 6 from 3`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 66 72 6F 6D 20 33 0D 0A`
40	Route: Speaker out 2: Source = Mic/line in 2	`set output 6 from 4`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 66 72 6F 6D 20 34 0D 0A`
41	Route: Speaker out 2: Source = Mixer 1	`set output 6 from 5`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 66 72 6F 6D 20 35 0D 0A`
42	Route: Speaker out 2: Source = Mixer 2	`set output 6 from 6`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 66 72 6F 6D 20 36 0D 0A`
43	Outputs: Dante out 1: Volume = {level} (0 to 100)	`set output 1 vol {level}`	`the level in place of {level}`
44	Outputs: Dante out 1: Volume = 0	`set output 1 vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 76 6F 6C 20 30 0D 0A`
45	Outputs: Dante out 1: Volume = 50	`set output 1 vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 76 6F 6C 20 35 30 0D 0A`
46	Outputs: Dante out 1: Volume = 100	`set output 1 vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 76 6F 6C 20 31 30 30 0D 0A`
47	Outputs: Dante out 2: Volume = {level} (0 to 100)	`set output 2 vol {level}`	`the level in place of {level}`
48	Outputs: Dante out 2: Volume = 0	`set output 2 vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 76 6F 6C 20 30 0D 0A`
49	Outputs: Dante out 2: Volume = 50	`set output 2 vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 76 6F 6C 20 35 30 0D 0A`
50	Outputs: Dante out 2: Volume = 100	`set output 2 vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 76 6F 6C 20 31 30 30 0D 0A`
51	Outputs: Line out 1: Volume = {level} (0 to 100)	`set output 3 vol {level}`	`the level in place of {level}`
52	Outputs: Line out 1: Volume = 0	`set output 3 vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 76 6F 6C 20 30 0D 0A`
53	Outputs: Line out 1: Volume = 50	`set output 3 vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 76 6F 6C 20 35 30 0D 0A`
54	Outputs: Line out 1: Volume = 100	`set output 3 vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 76 6F 6C 20 31 30 30 0D 0A`

55	Outputs: Line out 2: Volume = {level} (0 to 100)	`set output 4 vol {level}`	the level in place of {level}
56	Outputs: Line out 2: Volume = 0	`set output 4 vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 76 6F 6C 20 30 0D 0A`
57	Outputs: Line out 2: Volume = 50	`set output 4 vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 76 6F 6C 20 35 30 0D 0A`
58	Outputs: Line out 2: Volume = 100	`set output 4 vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 76 6F 6C 20 31 30 30 0D 0A`
59	Outputs: Speaker out 1: Volume = {level} (0 to 100)	`set output 5 vol {level}`	the level in place of {level}
60	Outputs: Speaker out 1: Volume = 0	`set output 5 vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 76 6F 6C 20 30 0D 0A`
61	Outputs: Speaker out 1: Volume = 50	`set output 5 vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 76 6F 6C 20 35 30 0D 0A`
62	Outputs: Speaker out 1: Volume = 100	`set output 5 vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 76 6F 6C 20 31 30 30 0D 0A`
63	Outputs: Speaker out 2: Volume = {level} (0 to 100)	`set output 6 vol {level}`	the level in place of {level}
64	Outputs: Speaker out 2: Volume = 0	`set output 6 vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 76 6F 6C 20 30 0D 0A`
65	Outputs: Speaker out 2: Volume = 50	`set output 6 vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 76 6F 6C 20 35 30 0D 0A`
66	Outputs: Speaker out 2: Volume = 100	`set output 6 vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 76 6F 6C 20 31 30 30 0D 0A`
67	Outputs: Dante out 1: Mute on	`set output 1 mute on`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 6D 75 74 65 20 6F 6E 0D 0A`
68	Outputs: Dante out 1: Mute off	`set output 1 mute off`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 6D 75 74 65 20 6F 66 66 0D 0A`
69	Outputs: Dante out 2: Mute on	`set output 2 mute on`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 6D 75 74 65 20 6F 6E 0D 0A`
70	Outputs: Dante out 2: Mute off	`set output 2 mute off`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 6D 75 74 65 20 6F 66 66 0D 0A`
71	Outputs: Line out 1: Mute on	`set output 3 mute on`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 6D 75 74 65 20 6F 6E 0D 0A`
72	Outputs: Line out 1: Mute off	`set output 3 mute off`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 6D 75 74 65 20 6F 66 66 0D 0A`
73	Outputs: Line out 2: Mute on	`set output 4 mute on`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 6D 75 74 65 20 6F 6E 0D 0A`
74	Outputs: Line out 2: Mute off	`set output 4 mute off`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 6D 75 74 65 20 6F 66 66 0D 0A`
75	Outputs: Speaker out 1: Mute on	`set output 5 mute on`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 6D 75 74 65 20 6F 6E 0D 0A`
76	Outputs: Speaker out 1: Mute off	`set output 5 mute off`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 6D 75 74 65 20 6F 66 66 0D 0A`
77	Outputs: Speaker out 2: Mute on	`set output 6 mute on`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 6D 75 74 65 20 6F 6E 0D 0A`
78	Outputs: Speaker out 2: Mute off	`set output 6 mute off`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 6D 75 74 65 20 6F 66 66 0D 0A`

79	Outputs: Dante out 1: Delay (ms) = 0	set output 1 delay 0	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 30 0D 0A
80	Outputs: Dante out 1: Delay (ms) = 1	set output 1 delay 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 0D 0A
81	Outputs: Dante out 1: Delay (ms) = 2	set output 1 delay 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 0D 0A
82	Outputs: Dante out 1: Delay (ms) = 3	set output 1 delay 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 0D 0A
83	Outputs: Dante out 1: Delay (ms) = 4	set output 1 delay 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 0D 0A
84	Outputs: Dante out 1: Delay (ms) = 5	set output 1 delay 5	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 35 0D 0A
85	Outputs: Dante out 1: Delay (ms) = 6	set output 1 delay 6	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 36 0D 0A
86	Outputs: Dante out 1: Delay (ms) = 7	set output 1 delay 7	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 37 0D 0A
87	Outputs: Dante out 1: Delay (ms) = 8	set output 1 delay 8	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 38 0D 0A
88	Outputs: Dante out 1: Delay (ms) = 9	set output 1 delay 9	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 39 0D 0A
89	Outputs: Dante out 1: Delay (ms) = 10	set output 1 delay 10	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 30 0D 0A
90	Outputs: Dante out 1: Delay (ms) = 11	set output 1 delay 11	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 31 0D 0A
91	Outputs: Dante out 1: Delay (ms) = 12	set output 1 delay 12	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 32 0D 0A
92	Outputs: Dante out 1: Delay (ms) = 13	set output 1 delay 13	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 33 0D 0A
93	Outputs: Dante out 1: Delay (ms) = 14	set output 1 delay 14	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 34 0D 0A
94	Outputs: Dante out 1: Delay (ms) = 15	set output 1 delay 15	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 35 0D 0A
95	Outputs: Dante out 1: Delay (ms) = 16	set output 1 delay 16	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 36 0D 0A
96	Outputs: Dante out 1: Delay (ms) = 17	set output 1 delay 17	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 37 0D 0A
97	Outputs: Dante out 1: Delay (ms) = 18	set output 1 delay 18	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 38 0D 0A
98	Outputs: Dante out 1: Delay (ms) = 19	set output 1 delay 19	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 31 39 0D 0A
99	Outputs: Dante out 1: Delay (ms) = 20	set output 1 delay 20	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 30 0D 0A
100	Outputs: Dante out 1: Delay (ms) = 21	set output 1 delay 21	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 31 0D 0A
101	Outputs: Dante out 1: Delay (ms) = 22	set output 1 delay 22	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 32 0D 0A
102	Outputs: Dante out 1: Delay (ms) = 23	set output 1 delay 23	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 33 0D 0A

103	Outputs: Dante out 1: Delay (ms) = 24	set output 1 delay 24	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 34 0D 0A
104	Outputs: Dante out 1: Delay (ms) = 25	set output 1 delay 25	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 35 0D 0A
105	Outputs: Dante out 1: Delay (ms) = 26	set output 1 delay 26	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 36 0D 0A
106	Outputs: Dante out 1: Delay (ms) = 27	set output 1 delay 27	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 37 0D 0A
107	Outputs: Dante out 1: Delay (ms) = 28	set output 1 delay 28	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 38 0D 0A
108	Outputs: Dante out 1: Delay (ms) = 29	set output 1 delay 29	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 32 39 0D 0A
109	Outputs: Dante out 1: Delay (ms) = 30	set output 1 delay 30	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 30 0D 0A
110	Outputs: Dante out 1: Delay (ms) = 31	set output 1 delay 31	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 31 0D 0A
111	Outputs: Dante out 1: Delay (ms) = 32	set output 1 delay 32	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 32 0D 0A
112	Outputs: Dante out 1: Delay (ms) = 33	set output 1 delay 33	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 33 0D 0A
113	Outputs: Dante out 1: Delay (ms) = 34	set output 1 delay 34	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 34 0D 0A
114	Outputs: Dante out 1: Delay (ms) = 35	set output 1 delay 35	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 35 0D 0A
115	Outputs: Dante out 1: Delay (ms) = 36	set output 1 delay 36	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 36 0D 0A
116	Outputs: Dante out 1: Delay (ms) = 37	set output 1 delay 37	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 37 0D 0A
117	Outputs: Dante out 1: Delay (ms) = 38	set output 1 delay 38	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 38 0D 0A
118	Outputs: Dante out 1: Delay (ms) = 39	set output 1 delay 39	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 33 39 0D 0A
119	Outputs: Dante out 1: Delay (ms) = 40	set output 1 delay 40	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 30 0D 0A
120	Outputs: Dante out 1: Delay (ms) = 41	set output 1 delay 41	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 31 0D 0A
121	Outputs: Dante out 1: Delay (ms) = 42	set output 1 delay 42	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 32 0D 0A
122	Outputs: Dante out 1: Delay (ms) = 43	set output 1 delay 43	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 33 0D 0A
123	Outputs: Dante out 1: Delay (ms) = 44	set output 1 delay 44	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 34 0D 0A
124	Outputs: Dante out 1: Delay (ms) = 45	set output 1 delay 45	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 35 0D 0A
125	Outputs: Dante out 1: Delay (ms) = 46	set output 1 delay 46	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 36 0D 0A
126	Outputs: Dante out 1: Delay (ms) = 47	set output 1 delay 47	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 37 0D 0A

127	Outputs: Dante out 1: Delay (ms) = 48	set output 1 delay 48	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 38 0D 0A
128	Outputs: Dante out 1: Delay (ms) = 49	set output 1 delay 49	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 34 39 0D 0A
129	Outputs: Dante out 1: Delay (ms) = 50	set output 1 delay 50	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 65 6C 61 79 20 35 30 0D 0A
130	Outputs: Dante out 2: Delay (ms) = 0	set output 2 delay 0	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 30 0D 0A
131	Outputs: Dante out 2: Delay (ms) = 1	set output 2 delay 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 0D 0A
132	Outputs: Dante out 2: Delay (ms) = 2	set output 2 delay 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 0D 0A
133	Outputs: Dante out 2: Delay (ms) = 3	set output 2 delay 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 0D 0A
134	Outputs: Dante out 2: Delay (ms) = 4	set output 2 delay 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 0D 0A
135	Outputs: Dante out 2: Delay (ms) = 5	set output 2 delay 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 35 0D 0A
136	Outputs: Dante out 2: Delay (ms) = 6	set output 2 delay 6	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 36 0D 0A
137	Outputs: Dante out 2: Delay (ms) = 7	set output 2 delay 7	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 37 0D 0A
138	Outputs: Dante out 2: Delay (ms) = 8	set output 2 delay 8	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 38 0D 0A
139	Outputs: Dante out 2: Delay (ms) = 9	set output 2 delay 9	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 39 0D 0A
140	Outputs: Dante out 2: Delay (ms) = 10	set output 2 delay 10	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 30 0D 0A
141	Outputs: Dante out 2: Delay (ms) = 11	set output 2 delay 11	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 31 0D 0A
142	Outputs: Dante out 2: Delay (ms) = 12	set output 2 delay 12	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 32 0D 0A
143	Outputs: Dante out 2: Delay (ms) = 13	set output 2 delay 13	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 33 0D 0A
144	Outputs: Dante out 2: Delay (ms) = 14	set output 2 delay 14	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 34 0D 0A
145	Outputs: Dante out 2: Delay (ms) = 15	set output 2 delay 15	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 35 0D 0A
146	Outputs: Dante out 2: Delay (ms) = 16	set output 2 delay 16	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 36 0D 0A
147	Outputs: Dante out 2: Delay (ms) = 17	set output 2 delay 17	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 37 0D 0A
148	Outputs: Dante out 2: Delay (ms) = 18	set output 2 delay 18	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 38 0D 0A
149	Outputs: Dante out 2: Delay (ms) = 19	set output 2 delay 19	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 31 39 0D 0A
150	Outputs: Dante out 2: Delay (ms) = 20	set output 2 delay 20	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 30 0D 0A

151	Outputs: Dante out 2: Delay (ms) = 21	set output 2 delay 21	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 31 0D 0A
152	Outputs: Dante out 2: Delay (ms) = 22	set output 2 delay 22	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 32 0D 0A
153	Outputs: Dante out 2: Delay (ms) = 23	set output 2 delay 23	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 33 0D 0A
154	Outputs: Dante out 2: Delay (ms) = 24	set output 2 delay 24	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 34 0D 0A
155	Outputs: Dante out 2: Delay (ms) = 25	set output 2 delay 25	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 35 0D 0A
156	Outputs: Dante out 2: Delay (ms) = 26	set output 2 delay 26	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 36 0D 0A
157	Outputs: Dante out 2: Delay (ms) = 27	set output 2 delay 27	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 37 0D 0A
158	Outputs: Dante out 2: Delay (ms) = 28	set output 2 delay 28	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 38 0D 0A
159	Outputs: Dante out 2: Delay (ms) = 29	set output 2 delay 29	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 32 39 0D 0A
160	Outputs: Dante out 2: Delay (ms) = 30	set output 2 delay 30	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 30 0D 0A
161	Outputs: Dante out 2: Delay (ms) = 31	set output 2 delay 31	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 31 0D 0A
162	Outputs: Dante out 2: Delay (ms) = 32	set output 2 delay 32	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 32 0D 0A
163	Outputs: Dante out 2: Delay (ms) = 33	set output 2 delay 33	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 33 0D 0A
164	Outputs: Dante out 2: Delay (ms) = 34	set output 2 delay 34	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 34 0D 0A
165	Outputs: Dante out 2: Delay (ms) = 35	set output 2 delay 35	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 35 0D 0A
166	Outputs: Dante out 2: Delay (ms) = 36	set output 2 delay 36	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 36 0D 0A
167	Outputs: Dante out 2: Delay (ms) = 37	set output 2 delay 37	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 37 0D 0A
168	Outputs: Dante out 2: Delay (ms) = 38	set output 2 delay 38	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 38 0D 0A
169	Outputs: Dante out 2: Delay (ms) = 39	set output 2 delay 39	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 33 39 0D 0A
170	Outputs: Dante out 2: Delay (ms) = 40	set output 2 delay 40	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 30 0D 0A
171	Outputs: Dante out 2: Delay (ms) = 41	set output 2 delay 41	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 31 0D 0A
172	Outputs: Dante out 2: Delay (ms) = 42	set output 2 delay 42	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 32 0D 0A
173	Outputs: Dante out 2: Delay (ms) = 43	set output 2 delay 43	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 33 0D 0A
174	Outputs: Dante out 2: Delay (ms) = 44	set output 2 delay 44	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 34 0D 0A

175	Outputs: Dante out 2: Delay (ms) = 45	set output 2 delay 45	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 35 0D 0A
176	Outputs: Dante out 2: Delay (ms) = 46	set output 2 delay 46	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 36 0D 0A
177	Outputs: Dante out 2: Delay (ms) = 47	set output 2 delay 47	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 37 0D 0A
178	Outputs: Dante out 2: Delay (ms) = 48	set output 2 delay 48	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 38 0D 0A
179	Outputs: Dante out 2: Delay (ms) = 49	set output 2 delay 49	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 34 39 0D 0A
180	Outputs: Dante out 2: Delay (ms) = 50	set output 2 delay 50	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 65 6C 61 79 20 35 30 0D 0A
181	Outputs: Line out 1: Delay (ms) = 0	set output 3 delay 0	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 30 0D 0A
182	Outputs: Line out 1: Delay (ms) = 1	set output 3 delay 1	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 0D 0A
183	Outputs: Line out 1: Delay (ms) = 2	set output 3 delay 2	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 0D 0A
184	Outputs: Line out 1: Delay (ms) = 3	set output 3 delay 3	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 0D 0A
185	Outputs: Line out 1: Delay (ms) = 4	set output 3 delay 4	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 0D 0A
186	Outputs: Line out 1: Delay (ms) = 5	set output 3 delay 5	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 35 0D 0A
187	Outputs: Line out 1: Delay (ms) = 6	set output 3 delay 6	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 36 0D 0A
188	Outputs: Line out 1: Delay (ms) = 7	set output 3 delay 7	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 37 0D 0A
189	Outputs: Line out 1: Delay (ms) = 8	set output 3 delay 8	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 38 0D 0A
190	Outputs: Line out 1: Delay (ms) = 9	set output 3 delay 9	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 39 0D 0A
191	Outputs: Line out 1: Delay (ms) = 10	set output 3 delay 10	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 30 0D 0A
192	Outputs: Line out 1: Delay (ms) = 11	set output 3 delay 11	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 31 0D 0A
193	Outputs: Line out 1: Delay (ms) = 12	set output 3 delay 12	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 32 0D 0A
194	Outputs: Line out 1: Delay (ms) = 13	set output 3 delay 13	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 33 0D 0A
195	Outputs: Line out 1: Delay (ms) = 14	set output 3 delay 14	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 34 0D 0A
196	Outputs: Line out 1: Delay (ms) = 15	set output 3 delay 15	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 35 0D 0A
197	Outputs: Line out 1: Delay (ms) = 16	set output 3 delay 16	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 36 0D 0A
198	Outputs: Line out 1: Delay (ms) = 17	set output 3 delay 17	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 37 0D 0A

199	Outputs: Line out 1: Delay (ms) = 18	set output 3 delay 18	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 38 0D 0A
200	Outputs: Line out 1: Delay (ms) = 19	set output 3 delay 19	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 31 39 0D 0A
201	Outputs: Line out 1: Delay (ms) = 20	set output 3 delay 20	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 30 0D 0A
202	Outputs: Line out 1: Delay (ms) = 21	set output 3 delay 21	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 31 0D 0A
203	Outputs: Line out 1: Delay (ms) = 22	set output 3 delay 22	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 32 0D 0A
204	Outputs: Line out 1: Delay (ms) = 23	set output 3 delay 23	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 33 0D 0A
205	Outputs: Line out 1: Delay (ms) = 24	set output 3 delay 24	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 34 0D 0A
206	Outputs: Line out 1: Delay (ms) = 25	set output 3 delay 25	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 35 0D 0A
207	Outputs: Line out 1: Delay (ms) = 26	set output 3 delay 26	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 36 0D 0A
208	Outputs: Line out 1: Delay (ms) = 27	set output 3 delay 27	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 37 0D 0A
209	Outputs: Line out 1: Delay (ms) = 28	set output 3 delay 28	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 38 0D 0A
210	Outputs: Line out 1: Delay (ms) = 29	set output 3 delay 29	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 32 39 0D 0A
211	Outputs: Line out 1: Delay (ms) = 30	set output 3 delay 30	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 30 0D 0A
212	Outputs: Line out 1: Delay (ms) = 31	set output 3 delay 31	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 31 0D 0A
213	Outputs: Line out 1: Delay (ms) = 32	set output 3 delay 32	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 32 0D 0A
214	Outputs: Line out 1: Delay (ms) = 33	set output 3 delay 33	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 33 0D 0A
215	Outputs: Line out 1: Delay (ms) = 34	set output 3 delay 34	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 34 0D 0A
216	Outputs: Line out 1: Delay (ms) = 35	set output 3 delay 35	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 35 0D 0A
217	Outputs: Line out 1: Delay (ms) = 36	set output 3 delay 36	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 36 0D 0A
218	Outputs: Line out 1: Delay (ms) = 37	set output 3 delay 37	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 37 0D 0A
219	Outputs: Line out 1: Delay (ms) = 38	set output 3 delay 38	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 38 0D 0A
220	Outputs: Line out 1: Delay (ms) = 39	set output 3 delay 39	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 33 39 0D 0A
221	Outputs: Line out 1: Delay (ms) = 40	set output 3 delay 40	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 30 0D 0A
222	Outputs: Line out 1: Delay (ms) = 41	set output 3 delay 41	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 31 0D 0A

223	Outputs: Line out 1: Delay (ms) = 42	set output 3 delay 42	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 32 0D 0A
224	Outputs: Line out 1: Delay (ms) = 43	set output 3 delay 43	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 33 0D 0A
225	Outputs: Line out 1: Delay (ms) = 44	set output 3 delay 44	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 34 0D 0A
226	Outputs: Line out 1: Delay (ms) = 45	set output 3 delay 45	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 35 0D 0A
227	Outputs: Line out 1: Delay (ms) = 46	set output 3 delay 46	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 36 0D 0A
228	Outputs: Line out 1: Delay (ms) = 47	set output 3 delay 47	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 37 0D 0A
229	Outputs: Line out 1: Delay (ms) = 48	set output 3 delay 48	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 38 0D 0A
230	Outputs: Line out 1: Delay (ms) = 49	set output 3 delay 49	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 34 39 0D 0A
231	Outputs: Line out 1: Delay (ms) = 50	set output 3 delay 50	73 65 74 20 6F 75 74 70 75 74 20 33 20 64 65 6C 61 79 20 35 30 0D 0A
232	Outputs: Line out 2: Delay (ms) = 0	set output 4 delay 0	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 30 0D 0A
233	Outputs: Line out 2: Delay (ms) = 1	set output 4 delay 1	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 0D 0A
234	Outputs: Line out 2: Delay (ms) = 2	set output 4 delay 2	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 0D 0A
235	Outputs: Line out 2: Delay (ms) = 3	set output 4 delay 3	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 0D 0A
236	Outputs: Line out 2: Delay (ms) = 4	set output 4 delay 4	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 0D 0A
237	Outputs: Line out 2: Delay (ms) = 5	set output 4 delay 5	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 35 0D 0A
238	Outputs: Line out 2: Delay (ms) = 6	set output 4 delay 6	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 36 0D 0A
239	Outputs: Line out 2: Delay (ms) = 7	set output 4 delay 7	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 37 0D 0A
240	Outputs: Line out 2: Delay (ms) = 8	set output 4 delay 8	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 38 0D 0A
241	Outputs: Line out 2: Delay (ms) = 9	set output 4 delay 9	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 39 0D 0A
242	Outputs: Line out 2: Delay (ms) = 10	set output 4 delay 10	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 30 0D 0A
243	Outputs: Line out 2: Delay (ms) = 11	set output 4 delay 11	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 31 0D 0A
244	Outputs: Line out 2: Delay (ms) = 12	set output 4 delay 12	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 32 0D 0A
245	Outputs: Line out 2: Delay (ms) = 13	set output 4 delay 13	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 33 0D 0A
246	Outputs: Line out 2: Delay (ms) = 14	set output 4 delay 14	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 34 0D 0A

247	Outputs: Line out 2: Delay (ms) = 15	set output 4 delay 15	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 35 0D 0A
248	Outputs: Line out 2: Delay (ms) = 16	set output 4 delay 16	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 36 0D 0A
249	Outputs: Line out 2: Delay (ms) = 17	set output 4 delay 17	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 37 0D 0A
250	Outputs: Line out 2: Delay (ms) = 18	set output 4 delay 18	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 38 0D 0A
251	Outputs: Line out 2: Delay (ms) = 19	set output 4 delay 19	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 31 39 0D 0A
252	Outputs: Line out 2: Delay (ms) = 20	set output 4 delay 20	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 30 0D 0A
253	Outputs: Line out 2: Delay (ms) = 21	set output 4 delay 21	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 31 0D 0A
254	Outputs: Line out 2: Delay (ms) = 22	set output 4 delay 22	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 32 0D 0A
255	Outputs: Line out 2: Delay (ms) = 23	set output 4 delay 23	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 33 0D 0A
256	Outputs: Line out 2: Delay (ms) = 24	set output 4 delay 24	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 34 0D 0A
257	Outputs: Line out 2: Delay (ms) = 25	set output 4 delay 25	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 35 0D 0A
258	Outputs: Line out 2: Delay (ms) = 26	set output 4 delay 26	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 36 0D 0A
259	Outputs: Line out 2: Delay (ms) = 27	set output 4 delay 27	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 37 0D 0A
260	Outputs: Line out 2: Delay (ms) = 28	set output 4 delay 28	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 38 0D 0A
261	Outputs: Line out 2: Delay (ms) = 29	set output 4 delay 29	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 32 39 0D 0A
262	Outputs: Line out 2: Delay (ms) = 30	set output 4 delay 30	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 30 0D 0A
263	Outputs: Line out 2: Delay (ms) = 31	set output 4 delay 31	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 31 0D 0A
264	Outputs: Line out 2: Delay (ms) = 32	set output 4 delay 32	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 32 0D 0A
265	Outputs: Line out 2: Delay (ms) = 33	set output 4 delay 33	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 33 0D 0A
266	Outputs: Line out 2: Delay (ms) = 34	set output 4 delay 34	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 34 0D 0A
267	Outputs: Line out 2: Delay (ms) = 35	set output 4 delay 35	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 35 0D 0A
268	Outputs: Line out 2: Delay (ms) = 36	set output 4 delay 36	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 36 0D 0A
269	Outputs: Line out 2: Delay (ms) = 37	set output 4 delay 37	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 37 0D 0A
270	Outputs: Line out 2: Delay (ms) = 38	set output 4 delay 38	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 38 0D 0A

271	Outputs: Line out 2: Delay (ms) = 39	set output 4 delay 39	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 33 39 0D 0A
272	Outputs: Line out 2: Delay (ms) = 40	set output 4 delay 40	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 30 0D 0A
273	Outputs: Line out 2: Delay (ms) = 41	set output 4 delay 41	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 31 0D 0A
274	Outputs: Line out 2: Delay (ms) = 42	set output 4 delay 42	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 32 0D 0A
275	Outputs: Line out 2: Delay (ms) = 43	set output 4 delay 43	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 33 0D 0A
276	Outputs: Line out 2: Delay (ms) = 44	set output 4 delay 44	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 34 0D 0A
277	Outputs: Line out 2: Delay (ms) = 45	set output 4 delay 45	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 35 0D 0A
278	Outputs: Line out 2: Delay (ms) = 46	set output 4 delay 46	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 36 0D 0A
279	Outputs: Line out 2: Delay (ms) = 47	set output 4 delay 47	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 37 0D 0A
280	Outputs: Line out 2: Delay (ms) = 48	set output 4 delay 48	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 38 0D 0A
281	Outputs: Line out 2: Delay (ms) = 49	set output 4 delay 49	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 34 39 0D 0A
282	Outputs: Line out 2: Delay (ms) = 50	set output 4 delay 50	73 65 74 20 6F 75 74 70 75 74 20 34 20 64 65 6C 61 79 20 35 30 0D 0A
283	Outputs: Speaker out 1: Delay (ms) = 0	set output 5 delay 0	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 30 0D 0A
284	Outputs: Speaker out 1: Delay (ms) = 1	set output 5 delay 1	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 0D 0A
285	Outputs: Speaker out 1: Delay (ms) = 2	set output 5 delay 2	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 0D 0A
286	Outputs: Speaker out 1: Delay (ms) = 3	set output 5 delay 3	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 0D 0A
287	Outputs: Speaker out 1: Delay (ms) = 4	set output 5 delay 4	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 0D 0A
288	Outputs: Speaker out 1: Delay (ms) = 5	set output 5 delay 5	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 35 0D 0A
289	Outputs: Speaker out 1: Delay (ms) = 6	set output 5 delay 6	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 36 0D 0A
290	Outputs: Speaker out 1: Delay (ms) = 7	set output 5 delay 7	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 37 0D 0A
291	Outputs: Speaker out 1: Delay (ms) = 8	set output 5 delay 8	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 38 0D 0A
292	Outputs: Speaker out 1: Delay (ms) = 9	set output 5 delay 9	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 39 0D 0A
293	Outputs: Speaker out 1: Delay (ms) = 10	set output 5 delay 10	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 30 0D 0A
294	Outputs: Speaker out 1: Delay (ms) = 11	set output 5 delay 11	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 31 0D 0A

295	Outputs: Speaker out 1: Delay (ms) = 12	set output 5 delay 12	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 32 0D 0A
296	Outputs: Speaker out 1: Delay (ms) = 13	set output 5 delay 13	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 33 0D 0A
297	Outputs: Speaker out 1: Delay (ms) = 14	set output 5 delay 14	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 34 0D 0A
298	Outputs: Speaker out 1: Delay (ms) = 15	set output 5 delay 15	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 35 0D 0A
299	Outputs: Speaker out 1: Delay (ms) = 16	set output 5 delay 16	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 36 0D 0A
300	Outputs: Speaker out 1: Delay (ms) = 17	set output 5 delay 17	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 37 0D 0A
301	Outputs: Speaker out 1: Delay (ms) = 18	set output 5 delay 18	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 38 0D 0A
302	Outputs: Speaker out 1: Delay (ms) = 19	set output 5 delay 19	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 31 39 0D 0A
303	Outputs: Speaker out 1: Delay (ms) = 20	set output 5 delay 20	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 30 0D 0A
304	Outputs: Speaker out 1: Delay (ms) = 21	set output 5 delay 21	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 31 0D 0A
305	Outputs: Speaker out 1: Delay (ms) = 22	set output 5 delay 22	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 32 0D 0A
306	Outputs: Speaker out 1: Delay (ms) = 23	set output 5 delay 23	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 33 0D 0A
307	Outputs: Speaker out 1: Delay (ms) = 24	set output 5 delay 24	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 34 0D 0A
308	Outputs: Speaker out 1: Delay (ms) = 25	set output 5 delay 25	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 35 0D 0A
309	Outputs: Speaker out 1: Delay (ms) = 26	set output 5 delay 26	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 36 0D 0A
310	Outputs: Speaker out 1: Delay (ms) = 27	set output 5 delay 27	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 37 0D 0A
311	Outputs: Speaker out 1: Delay (ms) = 28	set output 5 delay 28	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 38 0D 0A
312	Outputs: Speaker out 1: Delay (ms) = 29	set output 5 delay 29	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 32 39 0D 0A
313	Outputs: Speaker out 1: Delay (ms) = 30	set output 5 delay 30	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 30 0D 0A
314	Outputs: Speaker out 1: Delay (ms) = 31	set output 5 delay 31	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 31 0D 0A
315	Outputs: Speaker out 1: Delay (ms) = 32	set output 5 delay 32	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 32 0D 0A
316	Outputs: Speaker out 1: Delay (ms) = 33	set output 5 delay 33	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 33 0D 0A
317	Outputs: Speaker out 1: Delay (ms) = 34	set output 5 delay 34	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 34 0D 0A
318	Outputs: Speaker out 1: Delay (ms) = 35	set output 5 delay 35	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 35 0D 0A

319	Outputs: Speaker out 1: Delay (ms) = 36	set output 5 delay 36	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 36 0D 0A
320	Outputs: Speaker out 1: Delay (ms) = 37	set output 5 delay 37	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 37 0D 0A
321	Outputs: Speaker out 1: Delay (ms) = 38	set output 5 delay 38	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 38 0D 0A
322	Outputs: Speaker out 1: Delay (ms) = 39	set output 5 delay 39	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 33 39 0D 0A
323	Outputs: Speaker out 1: Delay (ms) = 40	set output 5 delay 40	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 30 0D 0A
324	Outputs: Speaker out 1: Delay (ms) = 41	set output 5 delay 41	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 31 0D 0A
325	Outputs: Speaker out 1: Delay (ms) = 42	set output 5 delay 42	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 32 0D 0A
326	Outputs: Speaker out 1: Delay (ms) = 43	set output 5 delay 43	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 33 0D 0A
327	Outputs: Speaker out 1: Delay (ms) = 44	set output 5 delay 44	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 34 0D 0A
328	Outputs: Speaker out 1: Delay (ms) = 45	set output 5 delay 45	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 35 0D 0A
329	Outputs: Speaker out 1: Delay (ms) = 46	set output 5 delay 46	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 36 0D 0A
330	Outputs: Speaker out 1: Delay (ms) = 47	set output 5 delay 47	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 37 0D 0A
331	Outputs: Speaker out 1: Delay (ms) = 48	set output 5 delay 48	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 38 0D 0A
332	Outputs: Speaker out 1: Delay (ms) = 49	set output 5 delay 49	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 34 39 0D 0A
333	Outputs: Speaker out 1: Delay (ms) = 50	set output 5 delay 50	73 65 74 20 6F 75 74 70 75 74 20 35 20 64 65 6C 61 79 20 35 30 0D 0A
334	Outputs: Speaker out 2: Delay (ms) = 0	set output 6 delay 0	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 30 0D 0A
335	Outputs: Speaker out 2: Delay (ms) = 1	set output 6 delay 1	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 0D 0A
336	Outputs: Speaker out 2: Delay (ms) = 2	set output 6 delay 2	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 0D 0A
337	Outputs: Speaker out 2: Delay (ms) = 3	set output 6 delay 3	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 0D 0A
338	Outputs: Speaker out 2: Delay (ms) = 4	set output 6 delay 4	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 0D 0A
339	Outputs: Speaker out 2: Delay (ms) = 5	set output 6 delay 5	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 35 0D 0A
340	Outputs: Speaker out 2: Delay (ms) = 6	set output 6 delay 6	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 36 0D 0A
341	Outputs: Speaker out 2: Delay (ms) = 7	set output 6 delay 7	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 37 0D 0A
342	Outputs: Speaker out 2: Delay (ms) = 8	set output 6 delay 8	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 38 0D 0A

343	Outputs: Speaker out 2: Delay (ms) = 9	set output 6 delay 9	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 39 0D 0A
344	Outputs: Speaker out 2: Delay (ms) = 10	set output 6 delay 10	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 30 0D 0A
345	Outputs: Speaker out 2: Delay (ms) = 11	set output 6 delay 11	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 31 0D 0A
346	Outputs: Speaker out 2: Delay (ms) = 12	set output 6 delay 12	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 32 0D 0A
347	Outputs: Speaker out 2: Delay (ms) = 13	set output 6 delay 13	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 33 0D 0A
348	Outputs: Speaker out 2: Delay (ms) = 14	set output 6 delay 14	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 34 0D 0A
349	Outputs: Speaker out 2: Delay (ms) = 15	set output 6 delay 15	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 35 0D 0A
350	Outputs: Speaker out 2: Delay (ms) = 16	set output 6 delay 16	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 36 0D 0A
351	Outputs: Speaker out 2: Delay (ms) = 17	set output 6 delay 17	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 37 0D 0A
352	Outputs: Speaker out 2: Delay (ms) = 18	set output 6 delay 18	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 38 0D 0A
353	Outputs: Speaker out 2: Delay (ms) = 19	set output 6 delay 19	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 31 39 0D 0A
354	Outputs: Speaker out 2: Delay (ms) = 20	set output 6 delay 20	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 30 0D 0A
355	Outputs: Speaker out 2: Delay (ms) = 21	set output 6 delay 21	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 31 0D 0A
356	Outputs: Speaker out 2: Delay (ms) = 22	set output 6 delay 22	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 32 0D 0A
357	Outputs: Speaker out 2: Delay (ms) = 23	set output 6 delay 23	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 33 0D 0A
358	Outputs: Speaker out 2: Delay (ms) = 24	set output 6 delay 24	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 34 0D 0A
359	Outputs: Speaker out 2: Delay (ms) = 25	set output 6 delay 25	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 35 0D 0A
360	Outputs: Speaker out 2: Delay (ms) = 26	set output 6 delay 26	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 36 0D 0A
361	Outputs: Speaker out 2: Delay (ms) = 27	set output 6 delay 27	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 37 0D 0A
362	Outputs: Speaker out 2: Delay (ms) = 28	set output 6 delay 28	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 38 0D 0A
363	Outputs: Speaker out 2: Delay (ms) = 29	set output 6 delay 29	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 32 39 0D 0A
364	Outputs: Speaker out 2: Delay (ms) = 30	set output 6 delay 30	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 30 0D 0A
365	Outputs: Speaker out 2: Delay (ms) = 31	set output 6 delay 31	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 31 0D 0A
366	Outputs: Speaker out 2: Delay (ms) = 32	set output 6 delay 32	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 32 0D 0A

367	Outputs: Speaker out 2: Delay (ms) = 33	set output 6 delay 33	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 33 0D 0A
368	Outputs: Speaker out 2: Delay (ms) = 34	set output 6 delay 34	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 34 0D 0A
369	Outputs: Speaker out 2: Delay (ms) = 35	set output 6 delay 35	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 35 0D 0A
370	Outputs: Speaker out 2: Delay (ms) = 36	set output 6 delay 36	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 36 0D 0A
371	Outputs: Speaker out 2: Delay (ms) = 37	set output 6 delay 37	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 37 0D 0A
372	Outputs: Speaker out 2: Delay (ms) = 38	set output 6 delay 38	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 38 0D 0A
373	Outputs: Speaker out 2: Delay (ms) = 39	set output 6 delay 39	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 33 39 0D 0A
374	Outputs: Speaker out 2: Delay (ms) = 40	set output 6 delay 40	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 30 0D 0A
375	Outputs: Speaker out 2: Delay (ms) = 41	set output 6 delay 41	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 31 0D 0A
376	Outputs: Speaker out 2: Delay (ms) = 42	set output 6 delay 42	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 32 0D 0A
377	Outputs: Speaker out 2: Delay (ms) = 43	set output 6 delay 43	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 33 0D 0A
378	Outputs: Speaker out 2: Delay (ms) = 44	set output 6 delay 44	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 34 0D 0A
379	Outputs: Speaker out 2: Delay (ms) = 45	set output 6 delay 45	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 35 0D 0A
380	Outputs: Speaker out 2: Delay (ms) = 46	set output 6 delay 46	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 36 0D 0A
381	Outputs: Speaker out 2: Delay (ms) = 47	set output 6 delay 47	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 37 0D 0A
382	Outputs: Speaker out 2: Delay (ms) = 48	set output 6 delay 48	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 38 0D 0A
383	Outputs: Speaker out 2: Delay (ms) = 49	set output 6 delay 49	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 34 39 0D 0A
384	Outputs: Speaker out 2: Delay (ms) = 50	set output 6 delay 50	73 65 74 20 6F 75 74 70 75 74 20 36 20 64 65 6C 61 79 20 35 30 0D 0A
385	Outputs: Dante out: Stereo on	set output 1 stereo on	73 65 74 20 6F 75 74 70 75 74 20 31 20 73 74 65 72 65 6F 20 6F 6E 0D 0A
386	Outputs: Dante out: Stereo off	set output 1 stereo off	73 65 74 20 6F 75 74 70 75 74 20 31 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A
387	Outputs: Line out: Stereo on	set output 2 stereo on	73 65 74 20 6F 75 74 70 75 74 20 32 20 73 74 65 72 65 6F 20 6F 6E 0D 0A
388	Outputs: Line out: Stereo off	set output 2 stereo off	73 65 74 20 6F 75 74 70 75 74 20 32 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A
389	Outputs: Speaker out: Stereo on	set output 3 stereo on	73 65 74 20 6F 75 74 70 75 74 20 33 20 73 74 65 72 65 6F 20 6F 6E 0D 0A
390	Outputs: Speaker out: Stereo off	set output 3 stereo off	73 65 74 20 6F 75 74 70 75 74 20 33 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A

391	Inputs: Dante in 1: Gain (dB) = -12	`set input 1 gain -12`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 31 32 0D 0A`
392	Inputs: Dante in 1: Gain (dB) = -11	`set input 1 gain -11`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 31 31 0D 0A`
393	Inputs: Dante in 1: Gain (dB) = -10	`set input 1 gain -10`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 31 30 0D 0A`
394	Inputs: Dante in 1: Gain (dB) = -9	`set input 1 gain -9`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 39 0D 0A`
395	Inputs: Dante in 1: Gain (dB) = -8	`set input 1 gain -8`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 38 0D 0A`
396	Inputs: Dante in 1: Gain (dB) = -7	`set input 1 gain -7`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 37 0D 0A`
397	Inputs: Dante in 1: Gain (dB) = -6	`set input 1 gain -6`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 36 0D 0A`
398	Inputs: Dante in 1: Gain (dB) = -5	`set input 1 gain -5`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 35 0D 0A`
399	Inputs: Dante in 1: Gain (dB) = -4	`set input 1 gain -4`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 34 0D 0A`
400	Inputs: Dante in 1: Gain (dB) = -3	`set input 1 gain -3`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 33 0D 0A`
401	Inputs: Dante in 1: Gain (dB) = -2	`set input 1 gain -2`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 32 0D 0A`
402	Inputs: Dante in 1: Gain (dB) = -1	`set input 1 gain -1`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 2D 31 0D 0A`
403	Inputs: Dante in 1: Gain (dB) = 0	`set input 1 gain 0`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 30 0D 0A`
404	Inputs: Dante in 1: Gain (dB) = 1	`set input 1 gain 1`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 31 0D 0A`
405	Inputs: Dante in 1: Gain (dB) = 2	`set input 1 gain 2`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 32 0D 0A`
406	Inputs: Dante in 1: Gain (dB) = 3	`set input 1 gain 3`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 33 0D 0A`
407	Inputs: Dante in 1: Gain (dB) = 4	`set input 1 gain 4`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 34 0D 0A`
408	Inputs: Dante in 1: Gain (dB) = 5	`set input 1 gain 5`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 35 0D 0A`
409	Inputs: Dante in 1: Gain (dB) = 6	`set input 1 gain 6`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 36 0D 0A`
410	Inputs: Dante in 1: Gain (dB) = 7	`set input 1 gain 7`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 37 0D 0A`
411	Inputs: Dante in 1: Gain (dB) = 8	`set input 1 gain 8`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 38 0D 0A`
412	Inputs: Dante in 1: Gain (dB) = 9	`set input 1 gain 9`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 39 0D 0A`
413	Inputs: Dante in 1: Gain (dB) = 10	`set input 1 gain 10`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 31 30 0D 0A`
414	Inputs: Dante in 1: Gain (dB) = 11	`set input 1 gain 11`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 31 31 0D 0A`

415	Inputs: Dante in 1: Gain (dB) = 12	`set input 1 gain 12`	`73 65 74 20 69 6E 70 75 74 20 31 20 67 61 69 6E 20 31 32 0D 0A`
416	Inputs: Dante in 2: Gain (dB) = -12	`set input 2 gain -12`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 31 32 0D 0A`
417	Inputs: Dante in 2: Gain (dB) = -11	`set input 2 gain -11`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 31 31 0D 0A`
418	Inputs: Dante in 2: Gain (dB) = -10	`set input 2 gain -10`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 31 30 0D 0A`
419	Inputs: Dante in 2: Gain (dB) = -9	`set input 2 gain -9`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 39 0D 0A`
420	Inputs: Dante in 2: Gain (dB) = -8	`set input 2 gain -8`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 38 0D 0A`
421	Inputs: Dante in 2: Gain (dB) = -7	`set input 2 gain -7`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 37 0D 0A`
422	Inputs: Dante in 2: Gain (dB) = -6	`set input 2 gain -6`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 36 0D 0A`
423	Inputs: Dante in 2: Gain (dB) = -5	`set input 2 gain -5`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 35 0D 0A`
424	Inputs: Dante in 2: Gain (dB) = -4	`set input 2 gain -4`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 34 0D 0A`
425	Inputs: Dante in 2: Gain (dB) = -3	`set input 2 gain -3`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 33 0D 0A`
426	Inputs: Dante in 2: Gain (dB) = -2	`set input 2 gain -2`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 32 0D 0A`
427	Inputs: Dante in 2: Gain (dB) = -1	`set input 2 gain -1`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 2D 31 0D 0A`
428	Inputs: Dante in 2: Gain (dB) = 0	`set input 2 gain 0`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 30 0D 0A`
429	Inputs: Dante in 2: Gain (dB) = 1	`set input 2 gain 1`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 31 0D 0A`
430	Inputs: Dante in 2: Gain (dB) = 2	`set input 2 gain 2`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 32 0D 0A`
431	Inputs: Dante in 2: Gain (dB) = 3	`set input 2 gain 3`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 33 0D 0A`
432	Inputs: Dante in 2: Gain (dB) = 4	`set input 2 gain 4`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 34 0D 0A`
433	Inputs: Dante in 2: Gain (dB) = 5	`set input 2 gain 5`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 35 0D 0A`
434	Inputs: Dante in 2: Gain (dB) = 6	`set input 2 gain 6`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 36 0D 0A`
435	Inputs: Dante in 2: Gain (dB) = 7	`set input 2 gain 7`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 37 0D 0A`
436	Inputs: Dante in 2: Gain (dB) = 8	`set input 2 gain 8`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 38 0D 0A`
437	Inputs: Dante in 2: Gain (dB) = 9	`set input 2 gain 9`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 39 0D 0A`
438	Inputs: Dante in 2: Gain (dB) = 10	`set input 2 gain 10`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 31 30 0D 0A`

439	Inputs: Dante in 2: Gain (dB) = 11	`set input 2 gain 11`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 31 31 0D 0A`
440	Inputs: Dante in 2: Gain (dB) = 12	`set input 2 gain 12`	`73 65 74 20 69 6E 70 75 74 20 32 20 67 61 69 6E 20 31 32 0D 0A`
441	Inputs: Mic/line in 1: Gain (dB) = -12	`set input 3 gain -12`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 31 32 0D 0A`
442	Inputs: Mic/line in 1: Gain (dB) = -11	`set input 3 gain -11`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 31 31 0D 0A`
443	Inputs: Mic/line in 1: Gain (dB) = -10	`set input 3 gain -10`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 31 30 0D 0A`
444	Inputs: Mic/line in 1: Gain (dB) = -9	`set input 3 gain -9`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 39 0D 0A`
445	Inputs: Mic/line in 1: Gain (dB) = -8	`set input 3 gain -8`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 38 0D 0A`
446	Inputs: Mic/line in 1: Gain (dB) = -7	`set input 3 gain -7`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 37 0D 0A`
447	Inputs: Mic/line in 1: Gain (dB) = -6	`set input 3 gain -6`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 36 0D 0A`
448	Inputs: Mic/line in 1: Gain (dB) = -5	`set input 3 gain -5`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 35 0D 0A`
449	Inputs: Mic/line in 1: Gain (dB) = -4	`set input 3 gain -4`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 34 0D 0A`
450	Inputs: Mic/line in 1: Gain (dB) = -3	`set input 3 gain -3`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 33 0D 0A`
451	Inputs: Mic/line in 1: Gain (dB) = -2	`set input 3 gain -2`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 32 0D 0A`
452	Inputs: Mic/line in 1: Gain (dB) = -1	`set input 3 gain -1`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 2D 31 0D 0A`
453	Inputs: Mic/line in 1: Gain (dB) = 0	`set input 3 gain 0`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 30 0D 0A`
454	Inputs: Mic/line in 1: Gain (dB) = 1	`set input 3 gain 1`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 31 0D 0A`
455	Inputs: Mic/line in 1: Gain (dB) = 2	`set input 3 gain 2`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 32 0D 0A`
456	Inputs: Mic/line in 1: Gain (dB) = 3	`set input 3 gain 3`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 33 0D 0A`
457	Inputs: Mic/line in 1: Gain (dB) = 4	`set input 3 gain 4`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 34 0D 0A`
458	Inputs: Mic/line in 1: Gain (dB) = 5	`set input 3 gain 5`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 35 0D 0A`
459	Inputs: Mic/line in 1: Gain (dB) = 6	`set input 3 gain 6`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 36 0D 0A`
460	Inputs: Mic/line in 1: Gain (dB) = 7	`set input 3 gain 7`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 37 0D 0A`
461	Inputs: Mic/line in 1: Gain (dB) = 8	`set input 3 gain 8`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 38 0D 0A`
462	Inputs: Mic/line in 1: Gain (dB) = 9	`set input 3 gain 9`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 39 0D 0A`

463	Inputs: Mic/line in 1: Gain (dB) = 10	`set input 3 gain 10`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 31 30 0D 0A`
464	Inputs: Mic/line in 1: Gain (dB) = 11	`set input 3 gain 11`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 31 31 0D 0A`
465	Inputs: Mic/line in 1: Gain (dB) = 12	`set input 3 gain 12`	`73 65 74 20 69 6E 70 75 74 20 33 20 67 61 69 6E 20 31 32 0D 0A`
466	Inputs: Mic/line in 2: Gain (dB) = -12	`set input 4 gain -12`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 31 32 0D 0A`
467	Inputs: Mic/line in 2: Gain (dB) = -11	`set input 4 gain -11`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 31 31 0D 0A`
468	Inputs: Mic/line in 2: Gain (dB) = -10	`set input 4 gain -10`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 31 30 0D 0A`
469	Inputs: Mic/line in 2: Gain (dB) = -9	`set input 4 gain -9`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 39 0D 0A`
470	Inputs: Mic/line in 2: Gain (dB) = -8	`set input 4 gain -8`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 38 0D 0A`
471	Inputs: Mic/line in 2: Gain (dB) = -7	`set input 4 gain -7`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 37 0D 0A`
472	Inputs: Mic/line in 2: Gain (dB) = -6	`set input 4 gain -6`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 36 0D 0A`
473	Inputs: Mic/line in 2: Gain (dB) = -5	`set input 4 gain -5`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 35 0D 0A`
474	Inputs: Mic/line in 2: Gain (dB) = -4	`set input 4 gain -4`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 34 0D 0A`
475	Inputs: Mic/line in 2: Gain (dB) = -3	`set input 4 gain -3`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 33 0D 0A`
476	Inputs: Mic/line in 2: Gain (dB) = -2	`set input 4 gain -2`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 32 0D 0A`
477	Inputs: Mic/line in 2: Gain (dB) = -1	`set input 4 gain -1`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 2D 31 0D 0A`
478	Inputs: Mic/line in 2: Gain (dB) = 0	`set input 4 gain 0`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 30 0D 0A`
479	Inputs: Mic/line in 2: Gain (dB) = 1	`set input 4 gain 1`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 31 0D 0A`
480	Inputs: Mic/line in 2: Gain (dB) = 2	`set input 4 gain 2`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 32 0D 0A`
481	Inputs: Mic/line in 2: Gain (dB) = 3	`set input 4 gain 3`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 33 0D 0A`
482	Inputs: Mic/line in 2: Gain (dB) = 4	`set input 4 gain 4`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 34 0D 0A`
483	Inputs: Mic/line in 2: Gain (dB) = 5	`set input 4 gain 5`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 35 0D 0A`
484	Inputs: Mic/line in 2: Gain (dB) = 6	`set input 4 gain 6`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 36 0D 0A`
485	Inputs: Mic/line in 2: Gain (dB) = 7	`set input 4 gain 7`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 37 0D 0A`
486	Inputs: Mic/line in 2: Gain (dB) = 8	`set input 4 gain 8`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 38 0D 0A`

487	Inputs: Mic/line in 2: Gain (dB) = 9	`set input 4 gain 9`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 39 0D 0A`
488	Inputs: Mic/line in 2: Gain (dB) = 10	`set input 4 gain 10`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 31 30 0D 0A`
489	Inputs: Mic/line in 2: Gain (dB) = 11	`set input 4 gain 11`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 31 31 0D 0A`
490	Inputs: Mic/line in 2: Gain (dB) = 12	`set input 4 gain 12`	`73 65 74 20 69 6E 70 75 74 20 34 20 67 61 69 6E 20 31 32 0D 0A`
491	Inputs: Dante in 1: Mute on	`set input 1 mute on`	`73 65 74 20 69 6E 70 75 74 20 31 20 6D 75 74 65 20 6F 6E 0D 0A`
492	Inputs: Dante in 1: Mute off	`set input 1 mute off`	`73 65 74 20 69 6E 70 75 74 20 31 20 6D 75 74 65 20 6F 66 66 0D 0A`
493	Inputs: Dante in 2: Mute on	`set input 2 mute on`	`73 65 74 20 69 6E 70 75 74 20 32 20 6D 75 74 65 20 6F 6E 0D 0A`
494	Inputs: Dante in 2: Mute off	`set input 2 mute off`	`73 65 74 20 69 6E 70 75 74 20 32 20 6D 75 74 65 20 6F 66 66 0D 0A`
495	Inputs: Mic/line in 1: Mute on	`set input 3 mute on`	`73 65 74 20 69 6E 70 75 74 20 33 20 6D 75 74 65 20 6F 6E 0D 0A`
496	Inputs: Mic/line in 1: Mute off	`set input 3 mute off`	`73 65 74 20 69 6E 70 75 74 20 33 20 6D 75 74 65 20 6F 66 66 0D 0A`
497	Inputs: Mic/line in 2: Mute on	`set input 4 mute on`	`73 65 74 20 69 6E 70 75 74 20 34 20 6D 75 74 65 20 6F 6E 0D 0A`
498	Inputs: Mic/line in 2: Mute off	`set input 4 mute off`	`73 65 74 20 69 6E 70 75 74 20 34 20 6D 75 74 65 20 6F 66 66 0D 0A`
499	Inputs: Dante in: Stereo on	`set input 1 stereo on`	`73 65 74 20 69 6E 70 75 74 20 31 20 73 74 65 72 65 6F 20 6F 6E 0D 0A`
500	Inputs: Dante in: Stereo off	`set input 1 stereo off`	`73 65 74 20 69 6E 70 75 74 20 31 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A`
501	Inputs: Mic/line in: Stereo on	`set input 2 stereo on`	`73 65 74 20 69 6E 70 75 74 20 32 20 73 74 65 72 65 6F 20 6F 6E 0D 0A`
502	Inputs: Mic/line in: Stereo off	`set input 2 stereo off`	`73 65 74 20 69 6E 70 75 74 20 32 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A`
503	Inputs: Dante in 1: Sensitivity = +24 dBu	`set input 3 sensitivity 1`	`73 65 74 20 69 6E 70 75 74 20 33 20 73 65 6E 73 69 74 69 76 69 74 79 20 31 0D 0A`
504	Inputs: Dante in 1: Sensitivity = +14 dBu	`set input 3 sensitivity 2`	`73 65 74 20 69 6E 70 75 74 20 33 20 73 65 6E 73 69 74 69 76 69 74 79 20 32 0D 0A`
505	Inputs: Dante in 1: Sensitivity = +4 dBu	`set input 3 sensitivity 3`	`73 65 74 20 69 6E 70 75 74 20 33 20 73 65 6E 73 69 74 69 76 69 74 79 20 33 0D 0A`
506	Inputs: Dante in 1: Sensitivity = 0 dBV	`set input 3 sensitivity 4`	`73 65 74 20 69 6E 70 75 74 20 33 20 73 65 6E 73 69 74 69 76 69 74 79 20 34 0D 0A`
507	Inputs: Dante in 1: Sensitivity = -18 dBV	`set input 3 sensitivity 5`	`73 65 74 20 69 6E 70 75 74 20 33 20 73 65 6E 73 69 74 69 76 69 74 79 20 35 0D 0A`
508	Inputs: Dante in 1: Sensitivity = -35 dBV	`set input 3 sensitivity 6`	`73 65 74 20 69 6E 70 75 74 20 33 20 73 65 6E 73 69 74 69 76 69 74 79 20 36 0D 0A`
509	Inputs: Dante in 2: Sensitivity = +24 dBu	`set input 4 sensitivity 1`	`73 65 74 20 69 6E 70 75 74 20 34 20 73 65 6E 73 69 74 69 76 69 74 79 20 31 0D 0A`
510	Inputs: Dante in 2: Sensitivity = +14 dBu	`set input 4 sensitivity 2`	`73 65 74 20 69 6E 70 75 74 20 34 20 73 65 6E 73 69 74 69 76 69 74 79 20 32 0D 0A`

511	Inputs: Dante in 2: Sensitivity = +4 dBu	`set input 4 sensitivity 3`	`73 65 74 20 69 6E 70 75 74 20 34 20 73 65 6E 73 69 74 69 76 69 74 79 20 33 0D 0A`
512	Inputs: Dante in 2: Sensitivity = 0 dBV	`set input 4 sensitivity 4`	`73 65 74 20 69 6E 70 75 74 20 34 20 73 65 6E 73 69 74 69 76 69 74 79 20 34 0D 0A`
513	Inputs: Dante in 2: Sensitivity = -18 dBV	`set input 4 sensitivity 5`	`73 65 74 20 69 6E 70 75 74 20 34 20 73 65 6E 73 69 74 69 76 69 74 79 20 35 0D 0A`
514	Inputs: Dante in 2: Sensitivity = -35 dBV	`set input 4 sensitivity 6`	`73 65 74 20 69 6E 70 75 74 20 34 20 73 65 6E 73 69 74 69 76 69 74 79 20 36 0D 0A`
515	System: Standby after no sound (min, 0 = never) = {level} (0 to 100)	`set auto stb {level}`	`the level in place of {level}`
516	System: Standby after no sound (min, 0 = never) = 0	`set auto stb 0`	`73 65 74 20 61 75 74 6F 20 73 74 62 20 30 0D 0A`
517	System: Standby after no sound (min, 0 = never) = 50	`set auto stb 50`	`73 65 74 20 61 75 74 6F 20 73 74 62 20 35 30 0D 0A`
518	System: Standby after no sound (min, 0 = never) = 100	`set auto stb 100`	`73 65 74 20 61 75 74 6F 20 73 74 62 20 31 30 30 0D 0A`
519	System: Front display = Always on	`set lcd on`	`73 65 74 20 6C 63 64 20 6F 6E 0D 0A`
520	System: Front display = Always off	`set lcd off`	`73 65 74 20 6C 63 64 20 6F 66 66 0D 0A`
521	System: Front display = 15 s	`set lcd 15`	`73 65 74 20 6C 63 64 20 31 35 0D 0A`
522	System: Front display = 30 s	`set lcd 30`	`73 65 74 20 6C 63 64 20 33 30 0D 0A`
523	System: Front display = 60 s	`set lcd 60`	`73 65 74 20 6C 63 64 20 36 30 0D 0A`
524	System: ID light = Always on	`set idled on`	`73 65 74 20 69 64 6C 65 64 20 6F 6E 0D 0A`
525	System: ID light = Always off	`set idled off`	`73 65 74 20 69 64 6C 65 64 20 6F 66 66 0D 0A`
526	System: ID light = 15 s	`set idled 15`	`73 65 74 20 69 64 6C 65 64 20 31 35 0D 0A`
527	System: ID light = 30 s	`set idled 30`	`73 65 74 20 69 64 6C 65 64 20 33 30 0D 0A`
528	System: ID light = 60 s	`set idled 60`	`73 65 74 20 69 64 6C 65 64 20 36 30 0D 0A`
529	Power: Power On	`set power on`	`73 65 74 20 70 6F 77 65 72 20 6F 6E 0D 0A`
530	Power: Power Standby	`set power off`	`73 65 74 20 70 6F 77 65 72 20 6F 66 66 0D 0A`
531	EQ: Dante out 1: EQ = Flat	`set output 1 eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
532	EQ: Dante out 1: EQ = Custom 1	`set output 1 eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
533	EQ: Dante out 1: EQ = Custom 2	`set output 1 eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
534	EQ: Dante out 2: EQ = Flat	`set output 2 eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
535	EQ: Dante out 2: EQ = Custom 1	`set output 2 eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
536	EQ: Dante out 2: EQ = Custom 2	`set output 2 eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
537	EQ: Line out 1: EQ = Flat	`set output 3 eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
538	EQ: Line out 1: EQ = Custom 1	`set output 3 eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
539	EQ: Line out 1: EQ = Custom 2	`set output 3 eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`

540	EQ: Line out 2: EQ = Flat	`set output 4 eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
541	EQ: Line out 2: EQ = Custom 1	`set output 4 eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
542	EQ: Line out 2: EQ = Custom 2	`set output 4 eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
543	EQ: Speaker out 1: EQ = Flat	`set output 5 eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
544	EQ: Speaker out 1: EQ = Custom 1	`set output 5 eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
545	EQ: Speaker out 1: EQ = Custom 2	`set output 5 eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
546	EQ: Speaker out 2: EQ = Flat	`set output 6 eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
547	EQ: Speaker out 2: EQ = Custom 1	`set output 6 eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
548	EQ: Speaker out 2: EQ = Custom 2	`set output 6 eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
549	EQ: Dante out: Same EQ left and right on	`set output 1 eq stereo on`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 71 20 73 74 65 72 65 6F 20 6F 6E 0D 0A`
550	EQ: Dante out: Same EQ left and right off	`set output 1 eq stereo off`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 71 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A`
551	EQ: Line out: Same EQ left and right on	`set output 2 eq stereo on`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 71 20 73 74 65 72 65 6F 20 6F 6E 0D 0A`
552	EQ: Line out: Same EQ left and right off	`set output 2 eq stereo off`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 71 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A`
553	EQ: Speaker out: Same EQ left and right on	`set output 3 eq stereo on`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 71 20 73 74 65 72 65 6F 20 6F 6E 0D 0A`
554	EQ: Speaker out: Same EQ left and right off	`set output 3 eq stereo off`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 71 20 73 74 65 72 65 6F 20 6F 66 66 0D 0A`
555	EQ: Dante out 1: Clear the EQ	`set output 1 eq clear`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 71 20 63 6C 65 61 72 0D 0A`
556	EQ: Dante out 2: Clear the EQ	`set output 2 eq clear`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 71 20 63 6C 65 61 72 0D 0A`
557	EQ: Line out 1: Clear the EQ	`set output 3 eq clear`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 71 20 63 6C 65 61 72 0D 0A`
558	EQ: Line out 2: Clear the EQ	`set output 4 eq clear`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 65 71 20 63 6C 65 61 72 0D 0A`
559	EQ: Speaker out 1: Clear the EQ	`set output 5 eq clear`	`73 65 74 20 6F 75 74 70 75 74 20 35 20 65 71 20 63 6C 65 61 72 0D 0A`
560	EQ: Speaker out 2: Clear the EQ	`set output 6 eq clear`	`73 65 74 20 6F 75 74 70 75 74 20 36 20 65 71 20 63 6C 65 61 72 0D 0A`
561	Presets: Presets 1	`set preset recall 1`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 31 0D 0A`
562	Presets: Presets 2	`set preset recall 2`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 32 0D 0A`
563	Presets: Presets 3	`set preset recall 3`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 33 0D 0A`

564	**Presets: Presets 4**	`set preset recall 4`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 34 0D 0A`
565	**Presets: Presets 5**	`set preset recall 5`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 35 0D 0A`
566	**Presets: Save 1**	`set preset save 1`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 31 0D 0A`
567	**Presets: Save 2**	`set preset save 2`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 32 0D 0A`
568	**Presets: Save 3**	`set preset save 3`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 33 0D 0A`
569	**Presets: Save 4**	`set preset save 4`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 34 0D 0A`
570	**Presets: Save 5**	`set preset save 5`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 35 0D 0A`
571	**Presets: Clear a preset 1**	`set preset clear 1`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 31 0D 0A`
572	**Presets: Clear a preset 2**	`set preset clear 2`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 32 0D 0A`
573	**Presets: Clear a preset 3**	`set preset clear 3`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 33 0D 0A`
574	**Presets: Clear a preset 4**	`set preset clear 4`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 34 0D 0A`
575	**Presets: Clear a preset 5**	`set preset clear 5`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 35 0D 0A`

4. READING THE UNIT BACK

Send these to read the unit back (on a timer, or after a change).

#	String	Bytes (hex)	The reply gives
1	`get master vol`	`67 65 74 20 6D 61 73 74 65 72 20 76 6F 6C 0D 0A`	Volume
2	`get master mute`	`67 65 74 20 6D 61 73 74 65 72 20 6D 75 74 65 0D 0A`	Mute everything
3	`get auto stb`	`67 65 74 20 61 75 74 6F 20 73 74 62 0D 0A`	Standby after no sound (min, 0 = never)
4	`get fw version`	`67 65 74 20 66 77 20 76 65 72 73 69 6F 6E 0D 0A`	Firmware

5. TROUBLESHOOTING

Nothing happens.
Check the unit's IP address and that TCP 8000 is open between the Tesira server and the unit (same network or VLAN, or routed; no firewall in between). Check the line ending is sent after each string.

The unit answers with an error.
The string or its value is not one it takes, or the unit is in standby: turn it on first.