SW-4X2PS-70M Tesira Command Sheet

For Tesira Command String blocks · Version 1.0.2

Every command the SW-4X2PS-70M takes over the network, as fixed strings for Tesira Command String blocks. The unit is controlled on its own control port (TCP 8000); no other KanexPro software is needed. The same strings, with their bytes, are in `KanexPro-SW-4X2PS-70M-Tesira-Command-Sheet-1.0.2.csv` for copying.

> **Before you start —** the Tesira server must reach the SW-4X2PS-70M on TCP port 8000. Give the unit a fixed IP address (or a DHCP reservation).

TABLE OF CONTENTS

1. Connection
2. Using the strings
3. Commands
4. Reading the unit back
5. Troubleshooting

1. CONNECTION

HOW THE UNIT IS CONTROLLED	
Transport	TCP, port 8000 (the unit's control port)
Line ending	CR LF (hex `0D 0A`), after every string
Pacing	One string at a time. The unit answers within about 1.5 s; wait for the answer before the next string.
A refused string	The unit answers with an error line.

2. USING THE STRINGS

1. Point the Command String block at the unit's IP address, TCP port 8000.
2. Add one command per row of section 3: its string, then the line ending (hex `0D 0A`).
3. Wire each command to the control that should send it. The Bytes column is the whole string as it goes on the wire, to compare with a network capture.

Settings that only the unit's own web page has (its network, logins and firmware) stay on that page.

3. COMMANDS

697 strings, and a template for each level with more values than fit a list.

#	Command	String	Bytes (hex, with the line ending)
1	**Show: All outputs: Source = USB-C 1**	`set output 0 source 1`	`73 65 74 20 6F 75 74 70 75 74 20 30 20 73 6F 75 72 63 65 20 31 0D 0A`
2	**Show: All outputs: Source = USB-C 2**	`set output 0 source 2`	`73 65 74 20 6F 75 74 70 75 74 20 30 20 73 6F 75 72 63 65 20 32 0D 0A`
3	**Show: All outputs: Source = HDMI 3**	`set output 0 source 3`	`73 65 74 20 6F 75 74 70 75 74 20 30 20 73 6F 75 72 63 65 20 33 0D 0A`
4	**Show: All outputs: Source = HDMI 4**	`set output 0 source 4`	`73 65 74 20 6F 75 74 70 75 74 20 30 20 73 6F 75 72 63 65 20 34 0D 0A`
5	**Show: HDMI out 1: Source = USB-C 1**	`set output 1 source 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 73 6F 75 72 63 65 20 31 0D 0A`
6	**Show: HDMI out 1: Source = USB-C 2**	`set output 1 source 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 73 6F 75 72 63 65 20 32 0D 0A`

7	Show: HDMI out 1: Source = HDMI 3	set output 1 source 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 73 6F 75 72 63 65 20 33 0D 0A
8	Show: HDMI out 1: Source = HDMI 4	set output 1 source 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 73 6F 75 72 63 65 20 34 0D 0A
9	Show: HDMI/HDBT out 2: Source = USB-C 1	set output 2 source 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 73 6F 75 72 63 65 20 31 0D 0A
10	Show: HDMI/HDBT out 2: Source = USB-C 2	set output 2 source 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 73 6F 75 72 63 65 20 32 0D 0A
11	Show: HDMI/HDBT out 2: Source = HDMI 3	set output 2 source 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 73 6F 75 72 63 65 20 33 0D 0A
12	Show: HDMI/HDBT out 2: Source = HDMI 4	set output 2 source 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 73 6F 75 72 63 65 20 34 0D 0A
13	Layout: HDMI out 1: Layout = Auto	set output 1 display 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 0D 0A
14	Layout: HDMI out 1: Layout = Single	set output 1 display 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 32 0D 0A
15	Layout: HDMI out 1: Layout = Dual-LR	set output 1 display 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 33 0D 0A
16	Layout: HDMI out 1: Layout = Dual-TB	set output 1 display 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 34 0D 0A
17	Layout: HDMI out 1: Layout = PIP-LT	set output 1 display 5	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 35 0D 0A
18	Layout: HDMI out 1: Layout = PIP-LB	set output 1 display 6	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 36 0D 0A
19	Layout: HDMI out 1: Layout = PIP-RT	set output 1 display 7	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 37 0D 0A
20	Layout: HDMI out 1: Layout = PIP-RB	set output 1 display 8	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 38 0D 0A
21	Layout: HDMI out 1: Layout = Triple-L	set output 1 display 9	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 39 0D 0A
22	Layout: HDMI out 1: Layout = Triple-R	set output 1 display 10	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 30 0D 0A
23	Layout: HDMI out 1: Layout = Triple-T	set output 1 display 11	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 31 0D 0A
24	Layout: HDMI out 1: Layout = Triple-B	set output 1 display 12	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 32 0D 0A
25	Layout: HDMI out 1: Layout = Quad-L	set output 1 display 13	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 33 0D 0A
26	Layout: HDMI out 1: Layout = Quad-R	set output 1 display 14	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 34 0D 0A
27	Layout: HDMI out 1: Layout = Quad-T	set output 1 display 15	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 35 0D 0A
28	Layout: HDMI out 1: Layout = Quad-B	set output 1 display 16	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 36 0D 0A
29	Layout: HDMI out 1: Layout = Quad-S	set output 1 display 17	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 37 0D 0A
30	Layout: HDMI out 1: Layout = Copy the other output	set output 1 display 18	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 38 0D 0A

31	Layout: HDMI out 1: Layout = Custom layout 1	set output 1 display 19	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 31 39 0D 0A
32	Layout: HDMI out 1: Layout = Custom layout 2	set output 1 display 20	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 32 30 0D 0A
33	Layout: HDMI out 1: Layout = Custom layout 3	set output 1 display 21	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 32 31 0D 0A
34	Layout: HDMI out 1: Layout = Custom layout 4	set output 1 display 22	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 32 32 0D 0A
35	Layout: HDMI out 1: Layout = Custom layout 5	set output 1 display 23	73 65 74 20 6F 75 74 70 75 74 20 31 20 64 69 73 70 6C 61 79 20 32 33 0D 0A
36	Layout: HDMI/HDBT out 2: Layout = Auto	set output 2 display 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 0D 0A
37	Layout: HDMI/HDBT out 2: Layout = Single	set output 2 display 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 32 0D 0A
38	Layout: HDMI/HDBT out 2: Layout = Dual-LR	set output 2 display 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 33 0D 0A
39	Layout: HDMI/HDBT out 2: Layout = Dual-TB	set output 2 display 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 34 0D 0A
40	Layout: HDMI/HDBT out 2: Layout = PIP-LT	set output 2 display 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 35 0D 0A
41	Layout: HDMI/HDBT out 2: Layout = PIP-LB	set output 2 display 6	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 36 0D 0A
42	Layout: HDMI/HDBT out 2: Layout = PIP-RT	set output 2 display 7	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 37 0D 0A
43	Layout: HDMI/HDBT out 2: Layout = PIP-RB	set output 2 display 8	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 38 0D 0A
44	Layout: HDMI/HDBT out 2: Layout = Triple-L	set output 2 display 9	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 39 0D 0A
45	Layout: HDMI/HDBT out 2: Layout = Triple-R	set output 2 display 10	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 30 0D 0A
46	Layout: HDMI/HDBT out 2: Layout = Triple-T	set output 2 display 11	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 31 0D 0A
47	Layout: HDMI/HDBT out 2: Layout = Triple-B	set output 2 display 12	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 32 0D 0A
48	Layout: HDMI/HDBT out 2: Layout = Quad-L	set output 2 display 13	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 33 0D 0A
49	Layout: HDMI/HDBT out 2: Layout = Quad-R	set output 2 display 14	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 34 0D 0A
50	Layout: HDMI/HDBT out 2: Layout = Quad-T	set output 2 display 15	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 35 0D 0A
51	Layout: HDMI/HDBT out 2: Layout = Quad-B	set output 2 display 16	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 36 0D 0A
52	Layout: HDMI/HDBT out 2: Layout = Quad-S	set output 2 display 17	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 37 0D 0A
53	Layout: HDMI/HDBT out 2: Layout = Copy the other output	set output 2 display 18	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 38 0D 0A
54	Layout: HDMI/HDBT out 2: Layout = Custom layout 1	set output 2 display 19	73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 31 39 0D 0A

55	Layout: HDMI/HDBT out 2: Layout = Custom layout 2	`set output 2 display 20`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 32 30 0D 0A`
56	Layout: HDMI/HDBT out 2: Layout = Custom layout 3	`set output 2 display 21`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 32 31 0D 0A`
57	Layout: HDMI/HDBT out 2: Layout = Custom layout 4	`set output 2 display 22`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 32 32 0D 0A`
58	Layout: HDMI/HDBT out 2: Layout = Custom layout 5	`set output 2 display 23`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 64 69 73 70 6C 61 79 20 32 33 0D 0A`
59	Sound: Volume = {level} (0 to 100)	`set master audio vol {level}`	`the level in place of {level}`
60	Sound: Volume = 0	`set master audio vol 0`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
61	Sound: Volume = 50	`set master audio vol 50`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
62	Sound: Volume = 100	`set master audio vol 100`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
63	Sound: Volume a step = Down	`set master audio vol -`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 76 6F 6C 2D 0D 0A`
64	Sound: Volume a step = Up	`set master audio vol +`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 76 6F 6C 2B 0D 0A`
65	Sound: Mute the sound on	`set master audio mute 1`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A`
66	Sound: Mute the sound off	`set master audio mute 0`	`73 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A`
67	Sound: HDMI out 1: Volume = {level} (0 to 100)	`set output 1 audio vol {level}`	`the level in place of {level}`
68	Sound: HDMI out 1: Volume = 0	`set output 1 audio vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
69	Sound: HDMI out 1: Volume = 50	`set output 1 audio vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
70	Sound: HDMI out 1: Volume = 100	`set output 1 audio vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
71	Sound: HDMI/HDBT out 2: Volume = {level} (0 to 100)	`set output 2 audio vol {level}`	`the level in place of {level}`
72	Sound: HDMI/HDBT out 2: Volume = 0	`set output 2 audio vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
73	Sound: HDMI/HDBT out 2: Volume = 50	`set output 2 audio vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
74	Sound: HDMI/HDBT out 2: Volume = 100	`set output 2 audio vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
75	Sound: Out 3: Volume = {level} (0 to 100)	`set output 3 audio vol {level}`	`the level in place of {level}`
76	Sound: Out 3: Volume = 0	`set output 3 audio vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
77	Sound: Out 3: Volume = 50	`set output 3 audio vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
78	Sound: Out 3: Volume = 100	`set output 3 audio vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`

79	Sound: Out 4: Volume = {level} (0 to 100)	`set output 4 audio vol {level}`	`the level in place of {level}`
80	Sound: Out 4: Volume = 0	`set output 4 audio vol 0`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
81	Sound: Out 4: Volume = 50	`set output 4 audio vol 50`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
82	Sound: Out 4: Volume = 100	`set output 4 audio vol 100`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
83	Sound: HDMI out 1: Mute on	`set output 1 audio mute 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A`
84	Sound: HDMI out 1: Mute off	`set output 1 audio mute 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A`
85	Sound: HDMI/HDBT out 2: Mute on	`set output 2 audio mute 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A`
86	Sound: HDMI/HDBT out 2: Mute off	`set output 2 audio mute 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A`
87	Sound: Out 3: Mute on	`set output 3 audio mute 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A`
88	Sound: Out 3: Mute off	`set output 3 audio mute 0`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A`
89	Sound: Out 4: Mute on	`set output 4 audio mute 1`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A`
90	Sound: Out 4: Mute off	`set output 4 audio mute 0`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A`
91	Picture: HDMI out 1: Blank picture and sound (AV mute) on	`set output 1 avmute 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 76 6D 75 74 65 20 31 0D 0A`
92	Picture: HDMI out 1: Blank picture and sound (AV mute) off	`set output 1 avmute 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 76 6D 75 74 65 20 30 0D 0A`
93	Picture: HDMI/HDBT out 2: Blank picture and sound (AV mute) on	`set output 2 avmute 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 76 6D 75 74 65 20 31 0D 0A`
94	Picture: HDMI/HDBT out 2: Blank picture and sound (AV mute) off	`set output 2 avmute 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 76 6D 75 74 65 20 30 0D 0A`
95	Picture: Out 3: Blank picture and sound (AV mute) on	`set output 3 avmute 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 76 6D 75 74 65 20 31 0D 0A`
96	Picture: Out 3: Blank picture and sound (AV mute) off	`set output 3 avmute 0`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 76 6D 75 74 65 20 30 0D 0A`
97	Picture: HDMI out 1: Freeze the picture on	`set output 1 freeze 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 65 65 7A 65 20 31 0D 0A`
98	Picture: HDMI out 1: Freeze the picture off	`set output 1 freeze 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 72 65 65 7A 65 20 30 0D 0A`
99	Picture: HDMI/HDBT out 2: Freeze the picture on	`set output 2 freeze 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 65 65 7A 65 20 31 0D 0A`
100	Picture: HDMI/HDBT out 2: Freeze the picture off	`set output 2 freeze 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 72 65 65 7A 65 20 30 0D 0A`
101	Picture: Out 3: Freeze the picture on	`set output 3 freeze 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 65 65 7A 65 20 31 0D 0A`
102	Picture: Out 3: Freeze the picture off	`set output 3 freeze 0`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 66 72 65 65 7A 65 20 30 0D 0A`

103	Power: Power On	`power on`	`70 6F 77 65 72 20 6F 6E 0D 0A`
104	Power: Power Standby	`power off`	`70 6F 77 65 72 20 6F 66 66 0D 0A`
105	Screen: Screen Screen on	`set cec power on`	`73 65 74 20 63 65 63 20 70 6F 77 65 72 20 6F 6E 0D 0A`
106	Screen: Screen Screen off	`set cec power off`	`73 65 74 20 63 65 63 20 70 6F 77 65 72 20 6F 66 66 0D 0A`
107	Presets: Presets 1	`set preset recall 1`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 31 0D 0A`
108	Presets: Presets 2	`set preset recall 2`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 32 0D 0A`
109	Presets: Presets 3	`set preset recall 3`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 33 0D 0A`
110	Presets: Presets 4	`set preset recall 4`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 34 0D 0A`
111	Presets: Presets 5	`set preset recall 5`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 35 0D 0A`
112	Presets: Presets 6	`set preset recall 6`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 36 0D 0A`
113	Presets: Presets 7	`set preset recall 7`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 37 0D 0A`
114	Presets: Presets 8	`set preset recall 8`	`73 65 74 20 70 72 65 73 65 74 20 72 65 63 61 6C 6C 20 38 0D 0A`
115	Presets: Save 1	`set preset save 1`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 31 0D 0A`
116	Presets: Save 2	`set preset save 2`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 32 0D 0A`
117	Presets: Save 3	`set preset save 3`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 33 0D 0A`
118	Presets: Save 4	`set preset save 4`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 34 0D 0A`
119	Presets: Save 5	`set preset save 5`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 35 0D 0A`
120	Presets: Save 6	`set preset save 6`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 36 0D 0A`
121	Presets: Save 7	`set preset save 7`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 37 0D 0A`
122	Presets: Save 8	`set preset save 8`	`73 65 74 20 70 72 65 73 65 74 20 73 61 76 65 20 38 0D 0A`
123	Output: HDMI out 1: Resolution = Auto	`set output 1 res 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 0D 0A`
124	Output: HDMI out 1: Resolution = 3840x2160p60	`set output 1 res 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 32 0D 0A`
125	Output: HDMI out 1: Resolution = 3840x2160p50	`set output 1 res 3`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 33 0D 0A`
126	Output: HDMI out 1: Resolution = 4096x2160p60	`set output 1 res 4`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 34 0D 0A`
127	Output: HDMI out 1: Resolution = 4096x2160p50	`set output 1 res 5`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 35 0D 0A`

128	Output: HDMI out 1: Resolution = 3840x2160p30	set output 1 res 6	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 36 0D 0A
129	Output: HDMI out 1: Resolution = 1920x1080p60	set output 1 res 7	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 37 0D 0A
130	Output: HDMI out 1: Resolution = 1920x1080p50	set output 1 res 8	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 38 0D 0A
131	Output: HDMI out 1: Resolution = 1920x1080i60	set output 1 res 9	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 39 0D 0A
132	Output: HDMI out 1: Resolution = 1920x1080i50	set output 1 res 10	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 30 0D 0A
133	Output: HDMI out 1: Resolution = 1280x720p60	set output 1 res 11	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 31 0D 0A
134	Output: HDMI out 1: Resolution = 1280x720p50	set output 1 res 12	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 32 0D 0A
135	Output: HDMI out 1: Resolution = 1360x768p60	set output 1 res 13	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 33 0D 0A
136	Output: HDMI out 1: Resolution = 1280x800p60	set output 1 res 14	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 34 0D 0A
137	Output: HDMI out 1: Resolution = 1920x1200p60RB	set output 1 res 15	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 35 0D 0A
138	Output: HDMI out 1: Resolution = 1024x768p60	set output 1 res 16	73 65 74 20 6F 75 74 70 75 74 20 31 20 72 65 73 20 31 36 0D 0A
139	Output: HDMI/HDBT out 2: Resolution = Auto	set output 2 res 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 0D 0A
140	Output: HDMI/HDBT out 2: Resolution = 3840x2160p60	set output 2 res 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 32 0D 0A
141	Output: HDMI/HDBT out 2: Resolution = 3840x2160p50	set output 2 res 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 33 0D 0A
142	Output: HDMI/HDBT out 2: Resolution = 4096x2160p60	set output 2 res 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 34 0D 0A
143	Output: HDMI/HDBT out 2: Resolution = 4096x2160p50	set output 2 res 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 35 0D 0A
144	Output: HDMI/HDBT out 2: Resolution = 3840x2160p30	set output 2 res 6	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 36 0D 0A
145	Output: HDMI/HDBT out 2: Resolution = 1920x1080p60	set output 2 res 7	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 37 0D 0A
146	Output: HDMI/HDBT out 2: Resolution = 1920x1080p50	set output 2 res 8	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 38 0D 0A
147	Output: HDMI/HDBT out 2: Resolution = 1920x1080i60	set output 2 res 9	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 39 0D 0A
148	Output: HDMI/HDBT out 2: Resolution = 1920x1080i50	set output 2 res 10	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 30 0D 0A
149	Output: HDMI/HDBT out 2: Resolution = 1280x720p60	set output 2 res 11	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 31 0D 0A
150	Output: HDMI/HDBT out 2: Resolution = 1280x720p50	set output 2 res 12	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 32 0D 0A
151	Output: HDMI/HDBT out 2: Resolution = 1360x768p60	set output 2 res 13	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 33 0D 0A

152	Output: HDMI/HDBT out 2: Resolution = 1280x800p60	set output 2 res 14	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 34 0D 0A
153	Output: HDMI/HDBT out 2: Resolution = 1920x1200p60RB	set output 2 res 15	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 35 0D 0A
154	Output: HDMI/HDBT out 2: Resolution = 1024x768p60	set output 2 res 16	73 65 74 20 6F 75 74 70 75 74 20 32 20 72 65 73 20 31 36 0D 0A
155	Output: Out 3: Resolution = Auto	set output 3 res 1	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 0D 0A
156	Output: Out 3: Resolution = 3840x2160p60	set output 3 res 2	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 32 0D 0A
157	Output: Out 3: Resolution = 3840x2160p50	set output 3 res 3	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 33 0D 0A
158	Output: Out 3: Resolution = 4096x2160p60	set output 3 res 4	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 34 0D 0A
159	Output: Out 3: Resolution = 4096x2160p50	set output 3 res 5	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 35 0D 0A
160	Output: Out 3: Resolution = 3840x2160p30	set output 3 res 6	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 36 0D 0A
161	Output: Out 3: Resolution = 1920x1080p60	set output 3 res 7	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 37 0D 0A
162	Output: Out 3: Resolution = 1920x1080p50	set output 3 res 8	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 38 0D 0A
163	Output: Out 3: Resolution = 1920x1080i60	set output 3 res 9	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 39 0D 0A
164	Output: Out 3: Resolution = 1920x1080i50	set output 3 res 10	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 30 0D 0A
165	Output: Out 3: Resolution = 1280x720p60	set output 3 res 11	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 31 0D 0A
166	Output: Out 3: Resolution = 1280x720p50	set output 3 res 12	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 32 0D 0A
167	Output: Out 3: Resolution = 1360x768p60	set output 3 res 13	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 33 0D 0A
168	Output: Out 3: Resolution = 1280x800p60	set output 3 res 14	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 34 0D 0A
169	Output: Out 3: Resolution = 1920x1200p60RB	set output 3 res 15	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 35 0D 0A
170	Output: Out 3: Resolution = 1024x768p60	set output 3 res 16	73 65 74 20 6F 75 74 70 75 74 20 33 20 72 65 73 20 31 36 0D 0A
171	Output: HDMI out 1: HDCP = Auto	set output 1 hdcp 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 68 64 63 70 20 31 0D 0A
172	Output: HDMI out 1: HDCP = HDCP 1.4	set output 1 hdcp 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 68 64 63 70 20 32 0D 0A
173	Output: HDMI out 1: HDCP = HDCP 2.2	set output 1 hdcp 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 68 64 63 70 20 33 0D 0A
174	Output: HDMI/HDBT out 2: HDCP = Auto	set output 2 hdcp 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 68 64 63 70 20 31 0D 0A
175	Output: HDMI/HDBT out 2: HDCP = HDCP 1.4	set output 2 hdcp 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 68 64 63 70 20 32 0D 0A

176	Output: HDMI/HDBT out 2: HDCP = HDCP 2.2	`set output 2 hdcp 3`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 68 64 63 70 20 33 0D 0A`
177	Output: Out 3: HDCP = Auto	`set output 3 hdcp 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 68 64 63 70 20 31 0D 0A`
178	Output: Out 3: HDCP = HDCP 1.4	`set output 3 hdcp 2`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 68 64 63 70 20 32 0D 0A`
179	Output: Out 3: HDCP = HDCP 2.2	`set output 3 hdcp 3`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 68 64 63 70 20 33 0D 0A`
180	Output: HDMI out 1: Output on on	`set output 1 enable 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 6E 61 62 6C 65 20 31 0D 0A`
181	Output: HDMI out 1: Output on off	`set output 1 enable 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 65 6E 61 62 6C 65 20 30 0D 0A`
182	Output: HDMI/HDBT out 2: Output on on	`set output 2 enable 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 6E 61 62 6C 65 20 31 0D 0A`
183	Output: HDMI/HDBT out 2: Output on off	`set output 2 enable 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 65 6E 61 62 6C 65 20 30 0D 0A`
184	Output: Out 3: Output on on	`set output 3 enable 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 6E 61 62 6C 65 20 31 0D 0A`
185	Output: Out 3: Output on off	`set output 3 enable 0`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 65 6E 61 62 6C 65 20 30 0D 0A`
186	Inputs: USB-C 1: EDID = Auto (HDBT or HDMI or HDBT+HDMI)	`set input 1 edid 1`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 0D 0A`
187	Inputs: USB-C 1: EDID = Copy HDMI Out 1	`set input 1 edid 2`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 32 0D 0A`
188	Inputs: USB-C 1: EDID = Copy HDMI Out 2	`set input 1 edid 3`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 33 0D 0A`
189	Inputs: USB-C 1: EDID = Copy HDBT Out 2	`set input 1 edid 4`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 34 0D 0A`
190	Inputs: USB-C 1: EDID = 4K2K60_444, Stereo Audio 2.0	`set input 1 edid 5`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 35 0D 0A`
191	Inputs: USB-C 1: EDID = 4K2K30_444, Stereo Audio 2.0	`set input 1 edid 6`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 36 0D 0A`
192	Inputs: USB-C 1: EDID = 1080P, Stereo Audio 2.0	`set input 1 edid 7`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 37 0D 0A`
193	Inputs: USB-C 1: EDID = 720p, Stereo Audio 2.0	`set input 1 edid 8`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 38 0D 0A`
194	Inputs: USB-C 1: EDID = 1920x1200, Stereo Audio 2.0	`set input 1 edid 9`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 39 0D 0A`
195	Inputs: USB-C 1: EDID = 1680x1050, Stereo Audio 2.0	`set input 1 edid 10`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 30 0D 0A`
196	Inputs: USB-C 1: EDID = 1600x1200, Stereo Audio 2.0	`set input 1 edid 11`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 31 0D 0A`
197	Inputs: USB-C 1: EDID = 1440x900, Stereo Audio 2.0	`set input 1 edid 12`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 32 0D 0A`
198	Inputs: USB-C 1: EDID = 1360x768, Stereo Audio 2.0	`set input 1 edid 13`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 33 0D 0A`
199	Inputs: USB-C 1: EDID = 1280x1024, Stereo Audio 2.0	`set input 1 edid 14`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 34 0D 0A`

200	Inputs: USB-C 1: EDID = 1024x768, Stereo Audio 2.0	`set input 1 edid 15`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 35 0D 0A`
201	Inputs: USB-C 1: EDID = User Defined 1	`set input 1 edid 16`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 36 0D 0A`
202	Inputs: USB-C 1: EDID = User Defined 2	`set input 1 edid 17`	`73 65 74 20 69 6E 70 75 74 20 31 20 65 64 69 64 20 31 37 0D 0A`
203	Inputs: USB-C 2: EDID = Auto (HDBT or HDMI or HDBT+HDMI)	`set input 2 edid 1`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 0D 0A`
204	Inputs: USB-C 2: EDID = Copy HDMI Out 1	`set input 2 edid 2`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 32 0D 0A`
205	Inputs: USB-C 2: EDID = Copy HDMI Out 2	`set input 2 edid 3`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 33 0D 0A`
206	Inputs: USB-C 2: EDID = Copy HDBT Out 2	`set input 2 edid 4`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 34 0D 0A`
207	Inputs: USB-C 2: EDID = 4K2K60_444, Stereo Audio 2.0	`set input 2 edid 5`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 35 0D 0A`
208	Inputs: USB-C 2: EDID = 4K2K30_444, Stereo Audio 2.0	`set input 2 edid 6`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 36 0D 0A`
209	Inputs: USB-C 2: EDID = 1080P, Stereo Audio 2.0	`set input 2 edid 7`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 37 0D 0A`
210	Inputs: USB-C 2: EDID = 720p, Stereo Audio 2.0	`set input 2 edid 8`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 38 0D 0A`
211	Inputs: USB-C 2: EDID = 1920x1200, Stereo Audio 2.0	`set input 2 edid 9`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 39 0D 0A`
212	Inputs: USB-C 2: EDID = 1680x1050, Stereo Audio 2.0	`set input 2 edid 10`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 30 0D 0A`
213	Inputs: USB-C 2: EDID = 1600x1200, Stereo Audio 2.0	`set input 2 edid 11`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 31 0D 0A`
214	Inputs: USB-C 2: EDID = 1440x900, Stereo Audio 2.0	`set input 2 edid 12`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 32 0D 0A`
215	Inputs: USB-C 2: EDID = 1360x768, Stereo Audio 2.0	`set input 2 edid 13`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 33 0D 0A`
216	Inputs: USB-C 2: EDID = 1280x1024, Stereo Audio 2.0	`set input 2 edid 14`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 34 0D 0A`
217	Inputs: USB-C 2: EDID = 1024x768, Stereo Audio 2.0	`set input 2 edid 15`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 35 0D 0A`
218	Inputs: USB-C 2: EDID = User Defined 1	`set input 2 edid 16`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 36 0D 0A`
219	Inputs: USB-C 2: EDID = User Defined 2	`set input 2 edid 17`	`73 65 74 20 69 6E 70 75 74 20 32 20 65 64 69 64 20 31 37 0D 0A`
220	Inputs: HDMI 3: EDID = Auto (HDBT or HDMI or HDBT+HDMI)	`set input 3 edid 1`	`73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 0D 0A`
221	Inputs: HDMI 3: EDID = Copy HDMI Out 1	`set input 3 edid 2`	`73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 32 0D 0A`
222	Inputs: HDMI 3: EDID = Copy HDMI Out 2	`set input 3 edid 3`	`73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 33 0D 0A`
223	Inputs: HDMI 3: EDID = Copy HDBT Out 2	`set input 3 edid 4`	`73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 34 0D 0A`

224	Inputs: HDMI 3: EDID = 4K2K60_444, Stereo Audio 2.0	set input 3 edid 5	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 35 0D 0A
225	Inputs: HDMI 3: EDID = 4K2K30_444, Stereo Audio 2.0	set input 3 edid 6	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 36 0D 0A
226	Inputs: HDMI 3: EDID = 1080P, Stereo Audio 2.0	set input 3 edid 7	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 37 0D 0A
227	Inputs: HDMI 3: EDID = 720p, Stereo Audio 2.0	set input 3 edid 8	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 38 0D 0A
228	Inputs: HDMI 3: EDID = 1920x1200, Stereo Audio 2.0	set input 3 edid 9	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 39 0D 0A
229	Inputs: HDMI 3: EDID = 1680x1050, Stereo Audio 2.0	set input 3 edid 10	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 30 0D 0A
230	Inputs: HDMI 3: EDID = 1600x1200, Stereo Audio 2.0	set input 3 edid 11	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 31 0D 0A
231	Inputs: HDMI 3: EDID = 1440x900, Stereo Audio 2.0	set input 3 edid 12	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 32 0D 0A
232	Inputs: HDMI 3: EDID = 1360x768, Stereo Audio 2.0	set input 3 edid 13	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 33 0D 0A
233	Inputs: HDMI 3: EDID = 1280x1024, Stereo Audio 2.0	set input 3 edid 14	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 34 0D 0A
234	Inputs: HDMI 3: EDID = 1024x768, Stereo Audio 2.0	set input 3 edid 15	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 35 0D 0A
235	Inputs: HDMI 3: EDID = User Defined 1	set input 3 edid 16	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 36 0D 0A
236	Inputs: HDMI 3: EDID = User Defined 2	set input 3 edid 17	73 65 74 20 69 6E 70 75 74 20 33 20 65 64 69 64 20 31 37 0D 0A
237	Inputs: HDMI 4: EDID = Auto (HDBT or HDMI or HDBT+HDMI)	set input 4 edid 1	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 0D 0A
238	Inputs: HDMI 4: EDID = Copy HDMI Out 1	set input 4 edid 2	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 32 0D 0A
239	Inputs: HDMI 4: EDID = Copy HDMI Out 2	set input 4 edid 3	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 33 0D 0A
240	Inputs: HDMI 4: EDID = Copy HDBT Out 2	set input 4 edid 4	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 34 0D 0A
241	Inputs: HDMI 4: EDID = 4K2K60_444, Stereo Audio 2.0	set input 4 edid 5	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 35 0D 0A
242	Inputs: HDMI 4: EDID = 4K2K30_444, Stereo Audio 2.0	set input 4 edid 6	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 36 0D 0A
243	Inputs: HDMI 4: EDID = 1080P, Stereo Audio 2.0	set input 4 edid 7	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 37 0D 0A
244	Inputs: HDMI 4: EDID = 720p, Stereo Audio 2.0	set input 4 edid 8	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 38 0D 0A
245	Inputs: HDMI 4: EDID = 1920x1200, Stereo Audio 2.0	set input 4 edid 9	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 39 0D 0A
246	Inputs: HDMI 4: EDID = 1680x1050, Stereo Audio 2.0	set input 4 edid 10	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 30 0D 0A
247	Inputs: HDMI 4: EDID = 1600x1200, Stereo Audio 2.0	set input 4 edid 11	73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 31 0D 0A

248	Inputs: HDMI 4: EDID = 1440x900, Stereo Audio 2.0	`set input 4 edid 12`	`73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 32 0D 0A`
249	Inputs: HDMI 4: EDID = 1360x768, Stereo Audio 2.0	`set input 4 edid 13`	`73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 33 0D 0A`
250	Inputs: HDMI 4: EDID = 1280x1024, Stereo Audio 2.0	`set input 4 edid 14`	`73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 34 0D 0A`
251	Inputs: HDMI 4: EDID = 1024x768, Stereo Audio 2.0	`set input 4 edid 15`	`73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 35 0D 0A`
252	Inputs: HDMI 4: EDID = User Defined 1	`set input 4 edid 16`	`73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 36 0D 0A`
253	Inputs: HDMI 4: EDID = User Defined 2	`set input 4 edid 17`	`73 65 74 20 69 6E 70 75 74 20 34 20 65 64 69 64 20 31 37 0D 0A`
254	Inputs: USB-C 1: Accept HDCP on	`set input 1 hdcp 1`	`73 65 74 20 69 6E 70 75 74 20 31 20 68 64 63 70 20 31 0D 0A`
255	Inputs: USB-C 1: Accept HDCP off	`set input 1 hdcp 0`	`73 65 74 20 69 6E 70 75 74 20 31 20 68 64 63 70 20 30 0D 0A`
256	Inputs: USB-C 2: Accept HDCP on	`set input 2 hdcp 1`	`73 65 74 20 69 6E 70 75 74 20 32 20 68 64 63 70 20 31 0D 0A`
257	Inputs: USB-C 2: Accept HDCP off	`set input 2 hdcp 0`	`73 65 74 20 69 6E 70 75 74 20 32 20 68 64 63 70 20 30 0D 0A`
258	Inputs: HDMI 3: Accept HDCP on	`set input 3 hdcp 1`	`73 65 74 20 69 6E 70 75 74 20 33 20 68 64 63 70 20 31 0D 0A`
259	Inputs: HDMI 3: Accept HDCP off	`set input 3 hdcp 0`	`73 65 74 20 69 6E 70 75 74 20 33 20 68 64 63 70 20 30 0D 0A`
260	Inputs: HDMI 4: Accept HDCP on	`set input 4 hdcp 1`	`73 65 74 20 69 6E 70 75 74 20 34 20 68 64 63 70 20 31 0D 0A`
261	Inputs: HDMI 4: Accept HDCP off	`set input 4 hdcp 0`	`73 65 74 20 69 6E 70 75 74 20 34 20 68 64 63 70 20 30 0D 0A`
262	Auto switching: Detect a new source by = Signal	`set output auto switch mode 1`	`73 65 74 20 6F 75 74 70 75 74 20 61 75 74 6F 20 73 77 69 74 63 68 20 6D 6F 64 65 20 31 0D 0A`
263	Auto switching: Detect a new source by = Source 5V	`set output auto switch mode 2`	`73 65 74 20 6F 75 74 70 75 74 20 61 75 74 6F 20 73 77 69 74 63 68 20 6D 6F 64 65 20 32 0D 0A`
264	Auto switching: HDMI out 1: When the source goes, switch to = Next input	`set output 1 fallback input 0`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 30 0D 0A`
265	Auto switching: HDMI out 1: When the source goes, switch to = USB-C 1	`set output 1 fallback input 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 31 0D 0A`
266	Auto switching: HDMI out 1: When the source goes, switch to = USB-C 2	`set output 1 fallback input 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 32 0D 0A`
267	Auto switching: HDMI out 1: When the source goes, switch to = HDMI 3	`set output 1 fallback input 3`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 33 0D 0A`
268	Auto switching: HDMI out 1: When the source goes, switch to = HDMI 4	`set output 1 fallback input 4`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 34 0D 0A`

269	Auto switching: HDMI out 1: When the source goes, switch to = RX HDMI	`set output 1 fallback input 5`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 35 0D 0A`
270	Auto switching: HDMI/HDBT out 2: When the source goes, switch to = Next input	`set output 2 fallback input 0`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 30 0D 0A`
271	Auto switching: HDMI/HDBT out 2: When the source goes, switch to = USB-C 1	`set output 2 fallback input 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 31 0D 0A`
272	Auto switching: HDMI/HDBT out 2: When the source goes, switch to = USB-C 2	`set output 2 fallback input 2`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 32 0D 0A`
273	Auto switching: HDMI/HDBT out 2: When the source goes, switch to = HDMI 3	`set output 2 fallback input 3`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 33 0D 0A`
274	Auto switching: HDMI/HDBT out 2: When the source goes, switch to = HDMI 4	`set output 2 fallback input 4`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 34 0D 0A`
275	Auto switching: HDMI/HDBT out 2: When the source goes, switch to = RX HDMI	`set output 2 fallback input 5`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 66 61 6C 6C 62 61 63 6B 20 69 6E 70 75 74 20 35 0D 0A`
276	Auto switching: HDMI out 1: Auto switching shows = Single source	`set output 1 auto layout 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 6C 61 79 6F 75 74 20 31 0D 0A`
277	Auto switching: HDMI out 1: Auto switching shows = Multiview	`set output 1 auto layout 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 6C 61 79 6F 75 74 20 32 0D 0A`
278	Auto switching: HDMI/HDBT out 2: Auto switching shows = Single source	`set output 2 auto layout 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 6C 61 79 6F 75 74 20 31 0D 0A`
279	Auto switching: HDMI/HDBT out 2: Auto switching shows = Multiview	`set output 2 auto layout 2`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 6C 61 79 6F 75 74 20 32 0D 0A`
280	Auto switching: HDMI out 1: Two sources = Dual-LR (Left-by-Right)	`set output 1 auto dual 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 31 0D 0A`
281	Auto switching: HDMI out 1: Two sources = Dual-TB (Top-by-Bottom)	`set output 1 auto dual 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 32 0D 0A`
282	Auto switching: HDMI out 1: Two sources = PIP-LT (Left-by-Top)	`set output 1 auto dual 3`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 33 0D 0A`
283	Auto switching: HDMI out 1: Two sources = PIP-LB (Left-by-Bottom)	`set output 1 auto dual 4`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 34 0D 0A`
284	Auto switching: HDMI out 1: Two sources = PIP-RT (Right-by-Top)	`set output 1 auto dual 5`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 35 0D 0A`
285	Auto switching: HDMI out 1: Two sources = PIP-RB (Right-by-Bottom)	`set output 1 auto dual 6`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 36 0D 0A`
286	Auto switching: HDMI out 1: Two sources = Dual User Defined	`set output 1 auto dual 7`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 64 75 61 6C 20 37 0D 0A`
287	Auto switching: HDMI/HDBT out 2: Two sources = Dual-LR (Left-by-Right)	`set output 2 auto dual 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 31 0D 0A`
288	Auto switching: HDMI/HDBT out 2: Two sources = Dual-TB (Top-by-Bottom)	`set output 2 auto dual 2`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 32 0D 0A`

289	Auto switching: HDMI/HDBT out 2: Two sources = PIP-LT (Left-by-Top)	set output 2 auto dual 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 33 0D 0A
290	Auto switching: HDMI/HDBT out 2: Two sources = PIP-LB (Left-by-Bottom)	set output 2 auto dual 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 34 0D 0A
291	Auto switching: HDMI/HDBT out 2: Two sources = PIP-RT (Right-by-Top)	set output 2 auto dual 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 35 0D 0A
292	Auto switching: HDMI/HDBT out 2: Two sources = PIP-RB (Right-by-Bottom)	set output 2 auto dual 6	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 36 0D 0A
293	Auto switching: HDMI/HDBT out 2: Two sources = Dual User Defined	set output 2 auto dual 7	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 64 75 61 6C 20 37 0D 0A
294	Auto switching: HDMI out 1: Three sources = Triple-L (Left)	set output 1 auto triple 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 74 72 69 70 6C 65 20 31 0D 0A
295	Auto switching: HDMI out 1: Three sources = Triple-R (Right)	set output 1 auto triple 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 74 72 69 70 6C 65 20 32 0D 0A
296	Auto switching: HDMI out 1: Three sources = Triple-T (Top)	set output 1 auto triple 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 74 72 69 70 6C 65 20 33 0D 0A
297	Auto switching: HDMI out 1: Three sources = Triple-B (Bottom)	set output 1 auto triple 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 74 72 69 70 6C 65 20 34 0D 0A
298	Auto switching: HDMI out 1: Three sources = Triple User Defined	set output 1 auto triple 5	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 74 72 69 70 6C 65 20 35 0D 0A
299	Auto switching: HDMI/HDBT out 2: Three sources = Triple-L (Left)	set output 2 auto triple 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 74 72 69 70 6C 65 20 31 0D 0A
300	Auto switching: HDMI/HDBT out 2: Three sources = Triple-R (Right)	set output 2 auto triple 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 74 72 69 70 6C 65 20 32 0D 0A
301	Auto switching: HDMI/HDBT out 2: Three sources = Triple-T (Top)	set output 2 auto triple 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 74 72 69 70 6C 65 20 33 0D 0A
302	Auto switching: HDMI/HDBT out 2: Three sources = Triple-B (Bottom)	set output 2 auto triple 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 74 72 69 70 6C 65 20 34 0D 0A
303	Auto switching: HDMI/HDBT out 2: Three sources = Triple User Defined	set output 2 auto triple 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 74 72 69 70 6C 65 20 35 0D 0A
304	Auto switching: HDMI out 1: Four sources = Quad-L (Left)	set output 1 auto quad 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 71 75 61 64 20 31 0D 0A
305	Auto switching: HDMI out 1: Four sources = Quad-R (Right)	set output 1 auto quad 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 71 75 61 64 20 32 0D 0A
306	Auto switching: HDMI out 1: Four sources = Quad-T (Top)	set output 1 auto quad 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 71 75 61 64 20 33 0D 0A
307	Auto switching: HDMI out 1: Four sources = Quad-B (Bottom)	set output 1 auto quad 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 71 75 61 64 20 34 0D 0A
308	Auto switching: HDMI out 1: Four sources = Quad-S (Square)	set output 1 auto quad 5	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 71 75 61 64 20 35 0D 0A
309	Auto switching: HDMI out 1: Four sources = Quad User Defined	set output 1 auto quad 6	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 74 6F 20 71 75 61 64 20 36 0D 0A
310	Auto switching: HDMI/HDBT out 2: Four sources = Quad-L (Left)	set output 2 auto quad 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 71 75 61 64 20 31 0D 0A
311	Auto switching: HDMI/HDBT out 2: Four sources = Quad-R (Right)	set output 2 auto quad 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 71 75 61 64 20 32 0D 0A

312	Auto switching: HDMI/HDBT out 2: Four sources = Quad-T (Top)	set output 2 auto quad 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 71 75 61 64 20 33 0D 0A
313	Auto switching: HDMI/HDBT out 2: Four sources = Quad-B (Bottom)	set output 2 auto quad 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 71 75 61 64 20 34 0D 0A
314	Auto switching: HDMI/HDBT out 2: Four sources = Quad-S (Square)	set output 2 auto quad 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 71 75 61 64 20 35 0D 0A
315	Auto switching: HDMI/HDBT out 2: Four sources = Quad User Defined	set output 2 auto quad 6	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 74 6F 20 71 75 61 64 20 36 0D 0A
316	Auto switching: Window 1: Window border = Off	set window 1 border 0	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 30 0D 0A
317	Auto switching: Window 1: Window border = Black	set window 1 border 1	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 31 0D 0A
318	Auto switching: Window 1: Window border = Red	set window 1 border 2	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 32 0D 0A
319	Auto switching: Window 1: Window border = Green	set window 1 border 3	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 33 0D 0A
320	Auto switching: Window 1: Window border = Blue	set window 1 border 4	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 34 0D 0A
321	Auto switching: Window 1: Window border = Yellow	set window 1 border 5	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 35 0D 0A
322	Auto switching: Window 1: Window border = Magenta	set window 1 border 6	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 36 0D 0A
323	Auto switching: Window 1: Window border = Cyan	set window 1 border 7	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 37 0D 0A
324	Auto switching: Window 1: Window border = White	set window 1 border 8	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 38 0D 0A
325	Auto switching: Window 1: Window border = Gray	set window 1 border 9	73 65 74 20 77 69 6E 64 6F 77 20 31 20 62 6F 72 64 65 72 20 39 0D 0A
326	Auto switching: Window 2: Window border = Off	set window 2 border 0	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 30 0D 0A
327	Auto switching: Window 2: Window border = Black	set window 2 border 1	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 31 0D 0A
328	Auto switching: Window 2: Window border = Red	set window 2 border 2	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 32 0D 0A
329	Auto switching: Window 2: Window border = Green	set window 2 border 3	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 33 0D 0A
330	Auto switching: Window 2: Window border = Blue	set window 2 border 4	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 34 0D 0A
331	Auto switching: Window 2: Window border = Yellow	set window 2 border 5	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 35 0D 0A
332	Auto switching: Window 2: Window border = Magenta	set window 2 border 6	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 36 0D 0A
333	Auto switching: Window 2: Window border = Cyan	set window 2 border 7	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 37 0D 0A
334	Auto switching: Window 2: Window border = White	set window 2 border 8	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 38 0D 0A
335	Auto switching: Window 2: Window border = Gray	set window 2 border 9	73 65 74 20 77 69 6E 64 6F 77 20 32 20 62 6F 72 64 65 72 20 39 0D 0A

336	Auto switching: Window 3: Window border = Off	set window 3 border 0	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 30 0D 0A
337	Auto switching: Window 3: Window border = Black	set window 3 border 1	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 31 0D 0A
338	Auto switching: Window 3: Window border = Red	set window 3 border 2	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 32 0D 0A
339	Auto switching: Window 3: Window border = Green	set window 3 border 3	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 33 0D 0A
340	Auto switching: Window 3: Window border = Blue	set window 3 border 4	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 34 0D 0A
341	Auto switching: Window 3: Window border = Yellow	set window 3 border 5	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 35 0D 0A
342	Auto switching: Window 3: Window border = Magenta	set window 3 border 6	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 36 0D 0A
343	Auto switching: Window 3: Window border = Cyan	set window 3 border 7	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 37 0D 0A
344	Auto switching: Window 3: Window border = White	set window 3 border 8	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 38 0D 0A
345	Auto switching: Window 3: Window border = Gray	set window 3 border 9	73 65 74 20 77 69 6E 64 6F 77 20 33 20 62 6F 72 64 65 72 20 39 0D 0A
346	Auto switching: Window 4: Window border = Off	set window 4 border 0	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 30 0D 0A
347	Auto switching: Window 4: Window border = Black	set window 4 border 1	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 31 0D 0A
348	Auto switching: Window 4: Window border = Red	set window 4 border 2	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 32 0D 0A
349	Auto switching: Window 4: Window border = Green	set window 4 border 3	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 33 0D 0A
350	Auto switching: Window 4: Window border = Blue	set window 4 border 4	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 34 0D 0A
351	Auto switching: Window 4: Window border = Yellow	set window 4 border 5	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 35 0D 0A
352	Auto switching: Window 4: Window border = Magenta	set window 4 border 6	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 36 0D 0A
353	Auto switching: Window 4: Window border = Cyan	set window 4 border 7	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 37 0D 0A
354	Auto switching: Window 4: Window border = White	set window 4 border 8	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 38 0D 0A
355	Auto switching: Window 4: Window border = Gray	set window 4 border 9	73 65 74 20 77 69 6E 64 6F 77 20 34 20 62 6F 72 64 65 72 20 39 0D 0A
356	Sound inputs: Main in 1: Plays the sound of = Follow the output's picture	set output main 1 audio 1	73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 31 20 61 75 64 69 6F 20 31 0D 0A
357	Sound inputs: Main in 1: Plays the sound of = USB-C 1	set output main 1 audio 2	73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 31 20 61 75 64 69 6F 20 32 0D 0A
358	Sound inputs: Main in 1: Plays the sound of = USB-C 2	set output main 1 audio 3	73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 31 20 61 75 64 69 6F 20 33 0D 0A
359	Sound inputs: Main in 1: Plays the sound of = HDMI 3	set output main 1 audio 4	73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 31 20 61 75 64 69 6F 20 34 0D 0A

360	Sound inputs: Main in 1: Plays the sound of = HDMI 4	`set output main 1 audio 5`	`73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 31 20 61 75 64 69 6F 20 35 0D 0A`
361	Sound inputs: Main in 2: Plays the sound of = Follow the output's picture	`set output main 2 audio 1`	`73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 32 20 61 75 64 69 6F 20 31 0D 0A`
362	Sound inputs: Main in 2: Plays the sound of = USB-C 1	`set output main 2 audio 2`	`73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 32 20 61 75 64 69 6F 20 32 0D 0A`
363	Sound inputs: Main in 2: Plays the sound of = USB-C 2	`set output main 2 audio 3`	`73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 32 20 61 75 64 69 6F 20 33 0D 0A`
364	Sound inputs: Main in 2: Plays the sound of = HDMI 3	`set output main 2 audio 4`	`73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 32 20 61 75 64 69 6F 20 34 0D 0A`
365	Sound inputs: Main in 2: Plays the sound of = HDMI 4	`set output main 2 audio 5`	`73 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 32 20 61 75 64 69 6F 20 35 0D 0A`
366	Sound inputs: USB-C 1: Level = {level} (0 to 100)	`set input 1 audio vol {level}`	`the level in place of {level}`
367	Sound inputs: USB-C 1: Level = 0	`set input 1 audio vol 0`	`73 65 74 20 69 6E 70 75 74 20 31 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
368	Sound inputs: USB-C 1: Level = 50	`set input 1 audio vol 50`	`73 65 74 20 69 6E 70 75 74 20 31 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
369	Sound inputs: USB-C 1: Level = 100	`set input 1 audio vol 100`	`73 65 74 20 69 6E 70 75 74 20 31 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
370	Sound inputs: USB-C 2: Level = {level} (0 to 100)	`set input 2 audio vol {level}`	`the level in place of {level}`
371	Sound inputs: USB-C 2: Level = 0	`set input 2 audio vol 0`	`73 65 74 20 69 6E 70 75 74 20 32 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
372	Sound inputs: USB-C 2: Level = 50	`set input 2 audio vol 50`	`73 65 74 20 69 6E 70 75 74 20 32 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
373	Sound inputs: USB-C 2: Level = 100	`set input 2 audio vol 100`	`73 65 74 20 69 6E 70 75 74 20 32 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
374	Sound inputs: HDMI 3: Level = {level} (0 to 100)	`set input 3 audio vol {level}`	`the level in place of {level}`
375	Sound inputs: HDMI 3: Level = 0	`set input 3 audio vol 0`	`73 65 74 20 69 6E 70 75 74 20 33 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
376	Sound inputs: HDMI 3: Level = 50	`set input 3 audio vol 50`	`73 65 74 20 69 6E 70 75 74 20 33 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
377	Sound inputs: HDMI 3: Level = 100	`set input 3 audio vol 100`	`73 65 74 20 69 6E 70 75 74 20 33 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
378	Sound inputs: HDMI 4: Level = {level} (0 to 100)	`set input 4 audio vol {level}`	`the level in place of {level}`
379	Sound inputs: HDMI 4: Level = 0	`set input 4 audio vol 0`	`73 65 74 20 69 6E 70 75 74 20 34 20 61 75 64 69 6F 20 76 6F 6C 20 30 0D 0A`
380	Sound inputs: HDMI 4: Level = 50	`set input 4 audio vol 50`	`73 65 74 20 69 6E 70 75 74 20 34 20 61 75 64 69 6F 20 76 6F 6C 20 35 30 0D 0A`
381	Sound inputs: HDMI 4: Level = 100	`set input 4 audio vol 100`	`73 65 74 20 69 6E 70 75 74 20 34 20 61 75 64 69 6F 20 76 6F 6C 20 31 30 30 0D 0A`
382	Sound inputs: USB-C 1: Mute on	`set input 1 audio mute 1`	`73 65 74 20 69 6E 70 75 74 20 31 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A`
383	Sound inputs: USB-C 1: Mute off	`set input 1 audio mute 0`	`73 65 74 20 69 6E 70 75 74 20 31 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A`

384	Sound inputs: USB-C 2: Mute on	set input 2 audio mute 1	73 65 74 20 69 6E 70 75 74 20 32 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A
385	Sound inputs: USB-C 2: Mute off	set input 2 audio mute 0	73 65 74 20 69 6E 70 75 74 20 32 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A
386	Sound inputs: HDMI 3: Mute on	set input 3 audio mute 1	73 65 74 20 69 6E 70 75 74 20 33 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A
387	Sound inputs: HDMI 3: Mute off	set input 3 audio mute 0	73 65 74 20 69 6E 70 75 74 20 33 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A
388	Sound inputs: HDMI 4: Mute on	set input 4 audio mute 1	73 65 74 20 69 6E 70 75 74 20 34 20 61 75 64 69 6F 20 6D 75 74 65 20 31 0D 0A
389	Sound inputs: HDMI 4: Mute off	set input 4 audio mute 0	73 65 74 20 69 6E 70 75 74 20 34 20 61 75 64 69 6F 20 6D 75 74 65 20 30 0D 0A
390	Sound outputs: HDMI out 1: Plays = Main in 1	set output 1 audio 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 31 0D 0A
391	Sound outputs: HDMI out 1: Plays = Main in 2	set output 1 audio 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 32 0D 0A
392	Sound outputs: HDMI out 1: Plays = Line in	set output 1 audio 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 33 0D 0A
393	Sound outputs: HDMI out 1: Plays = Dante in	set output 1 audio 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 34 0D 0A
394	Sound outputs: HDMI/HDBT out 2: Plays = Main in 1	set output 2 audio 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 31 0D 0A
395	Sound outputs: HDMI/HDBT out 2: Plays = Main in 2	set output 2 audio 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 32 0D 0A
396	Sound outputs: HDMI/HDBT out 2: Plays = Line in	set output 2 audio 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 33 0D 0A
397	Sound outputs: HDMI/HDBT out 2: Plays = Dante in	set output 2 audio 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 34 0D 0A
398	Sound outputs: Out 3: Plays = Main in 1	set output 3 audio 1	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 31 0D 0A
399	Sound outputs: Out 3: Plays = Main in 2	set output 3 audio 2	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 32 0D 0A
400	Sound outputs: Out 3: Plays = Line in	set output 3 audio 3	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 33 0D 0A
401	Sound outputs: Out 3: Plays = Dante in	set output 3 audio 4	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 34 0D 0A
402	Sound outputs: Out 4: Plays = Main in 1	set output 4 audio 1	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 31 0D 0A
403	Sound outputs: Out 4: Plays = Main in 2	set output 4 audio 2	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 32 0D 0A
404	Sound outputs: Out 4: Plays = Line in	set output 4 audio 3	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 33 0D 0A
405	Sound outputs: Out 4: Plays = Dante in	set output 4 audio 4	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 34 0D 0A
406	Sound outputs: HDMI out 1: Mix = Stereo	set output 1 audio mix 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 6D 69 78 20 31 0D 0A
407	Sound outputs: HDMI out 1: Mix = Left	set output 1 audio mix 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 6D 69 78 20 32 0D 0A

408	Sound outputs: HDMI out 1: Mix = Right	set output 1 audio mix 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 6D 69 78 20 33 0D 0A
409	Sound outputs: HDMI out 1: Mix = Left and right	set output 1 audio mix 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 6D 69 78 20 34 0D 0A
410	Sound outputs: HDMI/HDBT out 2: Mix = Stereo	set output 2 audio mix 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 6D 69 78 20 31 0D 0A
411	Sound outputs: HDMI/HDBT out 2: Mix = Left	set output 2 audio mix 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 6D 69 78 20 32 0D 0A
412	Sound outputs: HDMI/HDBT out 2: Mix = Right	set output 2 audio mix 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 6D 69 78 20 33 0D 0A
413	Sound outputs: HDMI/HDBT out 2: Mix = Left and right	set output 2 audio mix 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 6D 69 78 20 34 0D 0A
414	Sound outputs: Out 3: Mix = Stereo	set output 3 audio mix 1	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 6D 69 78 20 31 0D 0A
415	Sound outputs: Out 3: Mix = Left	set output 3 audio mix 2	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 6D 69 78 20 32 0D 0A
416	Sound outputs: Out 3: Mix = Right	set output 3 audio mix 3	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 6D 69 78 20 33 0D 0A
417	Sound outputs: Out 3: Mix = Left and right	set output 3 audio mix 4	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 6D 69 78 20 34 0D 0A
418	Sound outputs: Out 4: Mix = Stereo	set output 4 audio mix 1	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 6D 69 78 20 31 0D 0A
419	Sound outputs: Out 4: Mix = Left	set output 4 audio mix 2	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 6D 69 78 20 32 0D 0A
420	Sound outputs: Out 4: Mix = Right	set output 4 audio mix 3	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 6D 69 78 20 33 0D 0A
421	Sound outputs: Out 4: Mix = Left and right	set output 4 audio mix 4	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 6D 69 78 20 34 0D 0A
422	Sound outputs: HDMI out 1: Delay (ms) = 0	set output 1 audio delay 0	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 30 0D 0A
423	Sound outputs: HDMI out 1: Delay (ms) = 1	set output 1 audio delay 1	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 0D 0A
424	Sound outputs: HDMI out 1: Delay (ms) = 2	set output 1 audio delay 2	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 0D 0A
425	Sound outputs: HDMI out 1: Delay (ms) = 3	set output 1 audio delay 3	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 0D 0A
426	Sound outputs: HDMI out 1: Delay (ms) = 4	set output 1 audio delay 4	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 0D 0A
427	Sound outputs: HDMI out 1: Delay (ms) = 5	set output 1 audio delay 5	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 0D 0A
428	Sound outputs: HDMI out 1: Delay (ms) = 6	set output 1 audio delay 6	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 36 0D 0A
429	Sound outputs: HDMI out 1: Delay (ms) = 7	set output 1 audio delay 7	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 37 0D 0A
430	Sound outputs: HDMI out 1: Delay (ms) = 8	set output 1 audio delay 8	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 38 0D 0A
431	Sound outputs: HDMI out 1: Delay (ms) = 9	set output 1 audio delay 9	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 39 0D 0A

432	Sound outputs: HDMI out 1: Delay (ms) = 10	set output 1 audio delay 10	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 30 0D 0A
433	Sound outputs: HDMI out 1: Delay (ms) = 11	set output 1 audio delay 11	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 31 0D 0A
434	Sound outputs: HDMI out 1: Delay (ms) = 12	set output 1 audio delay 12	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 32 0D 0A
435	Sound outputs: HDMI out 1: Delay (ms) = 13	set output 1 audio delay 13	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 33 0D 0A
436	Sound outputs: HDMI out 1: Delay (ms) = 14	set output 1 audio delay 14	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 34 0D 0A
437	Sound outputs: HDMI out 1: Delay (ms) = 15	set output 1 audio delay 15	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 35 0D 0A
438	Sound outputs: HDMI out 1: Delay (ms) = 16	set output 1 audio delay 16	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 36 0D 0A
439	Sound outputs: HDMI out 1: Delay (ms) = 17	set output 1 audio delay 17	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 37 0D 0A
440	Sound outputs: HDMI out 1: Delay (ms) = 18	set output 1 audio delay 18	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 38 0D 0A
441	Sound outputs: HDMI out 1: Delay (ms) = 19	set output 1 audio delay 19	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 39 0D 0A
442	Sound outputs: HDMI out 1: Delay (ms) = 20	set output 1 audio delay 20	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 30 0D 0A
443	Sound outputs: HDMI out 1: Delay (ms) = 21	set output 1 audio delay 21	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 31 0D 0A
444	Sound outputs: HDMI out 1: Delay (ms) = 22	set output 1 audio delay 22	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 32 0D 0A
445	Sound outputs: HDMI out 1: Delay (ms) = 23	set output 1 audio delay 23	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 33 0D 0A
446	Sound outputs: HDMI out 1: Delay (ms) = 24	set output 1 audio delay 24	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 34 0D 0A
447	Sound outputs: HDMI out 1: Delay (ms) = 25	set output 1 audio delay 25	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 35 0D 0A
448	Sound outputs: HDMI out 1: Delay (ms) = 26	set output 1 audio delay 26	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 36 0D 0A
449	Sound outputs: HDMI out 1: Delay (ms) = 27	set output 1 audio delay 27	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 37 0D 0A
450	Sound outputs: HDMI out 1: Delay (ms) = 28	set output 1 audio delay 28	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 38 0D 0A
451	Sound outputs: HDMI out 1: Delay (ms) = 29	set output 1 audio delay 29	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 39 0D 0A
452	Sound outputs: HDMI out 1: Delay (ms) = 30	set output 1 audio delay 30	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 30 0D 0A
453	Sound outputs: HDMI out 1: Delay (ms) = 31	set output 1 audio delay 31	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 31 0D 0A
454	Sound outputs: HDMI out 1: Delay (ms) = 32	set output 1 audio delay 32	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 32 0D 0A
455	Sound outputs: HDMI out 1: Delay (ms) = 33	set output 1 audio delay 33	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 33 0D 0A

456	Sound outputs: HDMI out 1: Delay (ms) = 34	set output 1 audio delay 34	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 34 0D 0A
457	Sound outputs: HDMI out 1: Delay (ms) = 35	set output 1 audio delay 35	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 35 0D 0A
458	Sound outputs: HDMI out 1: Delay (ms) = 36	set output 1 audio delay 36	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 36 0D 0A
459	Sound outputs: HDMI out 1: Delay (ms) = 37	set output 1 audio delay 37	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 37 0D 0A
460	Sound outputs: HDMI out 1: Delay (ms) = 38	set output 1 audio delay 38	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 38 0D 0A
461	Sound outputs: HDMI out 1: Delay (ms) = 39	set output 1 audio delay 39	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 39 0D 0A
462	Sound outputs: HDMI out 1: Delay (ms) = 40	set output 1 audio delay 40	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 30 0D 0A
463	Sound outputs: HDMI out 1: Delay (ms) = 41	set output 1 audio delay 41	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 31 0D 0A
464	Sound outputs: HDMI out 1: Delay (ms) = 42	set output 1 audio delay 42	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 32 0D 0A
465	Sound outputs: HDMI out 1: Delay (ms) = 43	set output 1 audio delay 43	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 33 0D 0A
466	Sound outputs: HDMI out 1: Delay (ms) = 44	set output 1 audio delay 44	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 34 0D 0A
467	Sound outputs: HDMI out 1: Delay (ms) = 45	set output 1 audio delay 45	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 35 0D 0A
468	Sound outputs: HDMI out 1: Delay (ms) = 46	set output 1 audio delay 46	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 36 0D 0A
469	Sound outputs: HDMI out 1: Delay (ms) = 47	set output 1 audio delay 47	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 37 0D 0A
470	Sound outputs: HDMI out 1: Delay (ms) = 48	set output 1 audio delay 48	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 38 0D 0A
471	Sound outputs: HDMI out 1: Delay (ms) = 49	set output 1 audio delay 49	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 39 0D 0A
472	Sound outputs: HDMI out 1: Delay (ms) = 50	set output 1 audio delay 50	73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 30 0D 0A
473	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 0	set output 2 audio delay 0	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 30 0D 0A
474	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 1	set output 2 audio delay 1	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 0D 0A
475	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 2	set output 2 audio delay 2	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 0D 0A
476	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 3	set output 2 audio delay 3	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 0D 0A
477	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 4	set output 2 audio delay 4	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 0D 0A
478	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 5	set output 2 audio delay 5	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 0D 0A
479	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 6	set output 2 audio delay 6	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 36 0D 0A

480	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 7	set output 2 audio delay 7	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 37 0D 0A
481	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 8	set output 2 audio delay 8	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 38 0D 0A
482	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 9	set output 2 audio delay 9	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 39 0D 0A
483	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 10	set output 2 audio delay 10	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 30 0D 0A
484	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 11	set output 2 audio delay 11	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 31 0D 0A
485	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 12	set output 2 audio delay 12	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 32 0D 0A
486	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 13	set output 2 audio delay 13	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 33 0D 0A
487	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 14	set output 2 audio delay 14	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 34 0D 0A
488	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 15	set output 2 audio delay 15	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 35 0D 0A
489	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 16	set output 2 audio delay 16	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 36 0D 0A
490	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 17	set output 2 audio delay 17	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 37 0D 0A
491	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 18	set output 2 audio delay 18	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 38 0D 0A
492	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 19	set output 2 audio delay 19	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 39 0D 0A
493	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 20	set output 2 audio delay 20	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 30 0D 0A
494	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 21	set output 2 audio delay 21	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 31 0D 0A
495	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 22	set output 2 audio delay 22	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 32 0D 0A
496	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 23	set output 2 audio delay 23	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 33 0D 0A
497	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 24	set output 2 audio delay 24	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 34 0D 0A
498	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 25	set output 2 audio delay 25	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 35 0D 0A
499	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 26	set output 2 audio delay 26	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 36 0D 0A
500	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 27	set output 2 audio delay 27	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 37 0D 0A
501	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 28	set output 2 audio delay 28	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 38 0D 0A
502	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 29	set output 2 audio delay 29	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 39 0D 0A
503	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 30	set output 2 audio delay 30	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 30 0D 0A

504	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 31	set output 2 audio delay 31	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 31 0D 0A
505	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 32	set output 2 audio delay 32	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 32 0D 0A
506	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 33	set output 2 audio delay 33	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 33 0D 0A
507	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 34	set output 2 audio delay 34	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 34 0D 0A
508	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 35	set output 2 audio delay 35	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 35 0D 0A
509	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 36	set output 2 audio delay 36	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 36 0D 0A
510	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 37	set output 2 audio delay 37	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 37 0D 0A
511	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 38	set output 2 audio delay 38	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 38 0D 0A
512	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 39	set output 2 audio delay 39	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 39 0D 0A
513	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 40	set output 2 audio delay 40	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 30 0D 0A
514	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 41	set output 2 audio delay 41	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 31 0D 0A
515	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 42	set output 2 audio delay 42	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 32 0D 0A
516	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 43	set output 2 audio delay 43	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 33 0D 0A
517	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 44	set output 2 audio delay 44	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 34 0D 0A
518	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 45	set output 2 audio delay 45	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 35 0D 0A
519	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 46	set output 2 audio delay 46	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 36 0D 0A
520	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 47	set output 2 audio delay 47	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 37 0D 0A
521	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 48	set output 2 audio delay 48	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 38 0D 0A
522	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 49	set output 2 audio delay 49	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 39 0D 0A
523	Sound outputs: HDMI/HDBT out 2: Delay (ms) = 50	set output 2 audio delay 50	73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 30 0D 0A
524	Sound outputs: Out 3: Delay (ms) = 0	set output 3 audio delay 0	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 30 0D 0A
525	Sound outputs: Out 3: Delay (ms) = 1	set output 3 audio delay 1	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 0D 0A
526	Sound outputs: Out 3: Delay (ms) = 2	set output 3 audio delay 2	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 0D 0A
527	Sound outputs: Out 3: Delay (ms) = 3	set output 3 audio delay 3	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 0D 0A

528	Sound outputs: Out 3: Delay (ms) = 4	set output 3 audio delay 4	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 0D 0A
529	Sound outputs: Out 3: Delay (ms) = 5	set output 3 audio delay 5	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 0D 0A
530	Sound outputs: Out 3: Delay (ms) = 6	set output 3 audio delay 6	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 36 0D 0A
531	Sound outputs: Out 3: Delay (ms) = 7	set output 3 audio delay 7	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 37 0D 0A
532	Sound outputs: Out 3: Delay (ms) = 8	set output 3 audio delay 8	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 38 0D 0A
533	Sound outputs: Out 3: Delay (ms) = 9	set output 3 audio delay 9	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 39 0D 0A
534	Sound outputs: Out 3: Delay (ms) = 10	set output 3 audio delay 10	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 30 0D 0A
535	Sound outputs: Out 3: Delay (ms) = 11	set output 3 audio delay 11	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 31 0D 0A
536	Sound outputs: Out 3: Delay (ms) = 12	set output 3 audio delay 12	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 32 0D 0A
537	Sound outputs: Out 3: Delay (ms) = 13	set output 3 audio delay 13	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 33 0D 0A
538	Sound outputs: Out 3: Delay (ms) = 14	set output 3 audio delay 14	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 34 0D 0A
539	Sound outputs: Out 3: Delay (ms) = 15	set output 3 audio delay 15	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 35 0D 0A
540	Sound outputs: Out 3: Delay (ms) = 16	set output 3 audio delay 16	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 36 0D 0A
541	Sound outputs: Out 3: Delay (ms) = 17	set output 3 audio delay 17	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 37 0D 0A
542	Sound outputs: Out 3: Delay (ms) = 18	set output 3 audio delay 18	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 38 0D 0A
543	Sound outputs: Out 3: Delay (ms) = 19	set output 3 audio delay 19	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 39 0D 0A
544	Sound outputs: Out 3: Delay (ms) = 20	set output 3 audio delay 20	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 30 0D 0A
545	Sound outputs: Out 3: Delay (ms) = 21	set output 3 audio delay 21	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 31 0D 0A
546	Sound outputs: Out 3: Delay (ms) = 22	set output 3 audio delay 22	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 32 0D 0A
547	Sound outputs: Out 3: Delay (ms) = 23	set output 3 audio delay 23	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 33 0D 0A
548	Sound outputs: Out 3: Delay (ms) = 24	set output 3 audio delay 24	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 34 0D 0A
549	Sound outputs: Out 3: Delay (ms) = 25	set output 3 audio delay 25	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 35 0D 0A
550	Sound outputs: Out 3: Delay (ms) = 26	set output 3 audio delay 26	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 36 0D 0A
551	Sound outputs: Out 3: Delay (ms) = 27	set output 3 audio delay 27	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 37 0D 0A

552	Sound outputs: Out 3: Delay (ms) = 28	set output 3 audio delay 28	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 38 0D 0A
553	Sound outputs: Out 3: Delay (ms) = 29	set output 3 audio delay 29	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 39 0D 0A
554	Sound outputs: Out 3: Delay (ms) = 30	set output 3 audio delay 30	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 30 0D 0A
555	Sound outputs: Out 3: Delay (ms) = 31	set output 3 audio delay 31	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 31 0D 0A
556	Sound outputs: Out 3: Delay (ms) = 32	set output 3 audio delay 32	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 32 0D 0A
557	Sound outputs: Out 3: Delay (ms) = 33	set output 3 audio delay 33	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 33 0D 0A
558	Sound outputs: Out 3: Delay (ms) = 34	set output 3 audio delay 34	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 34 0D 0A
559	Sound outputs: Out 3: Delay (ms) = 35	set output 3 audio delay 35	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 35 0D 0A
560	Sound outputs: Out 3: Delay (ms) = 36	set output 3 audio delay 36	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 36 0D 0A
561	Sound outputs: Out 3: Delay (ms) = 37	set output 3 audio delay 37	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 37 0D 0A
562	Sound outputs: Out 3: Delay (ms) = 38	set output 3 audio delay 38	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 38 0D 0A
563	Sound outputs: Out 3: Delay (ms) = 39	set output 3 audio delay 39	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 39 0D 0A
564	Sound outputs: Out 3: Delay (ms) = 40	set output 3 audio delay 40	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 30 0D 0A
565	Sound outputs: Out 3: Delay (ms) = 41	set output 3 audio delay 41	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 31 0D 0A
566	Sound outputs: Out 3: Delay (ms) = 42	set output 3 audio delay 42	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 32 0D 0A
567	Sound outputs: Out 3: Delay (ms) = 43	set output 3 audio delay 43	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 33 0D 0A
568	Sound outputs: Out 3: Delay (ms) = 44	set output 3 audio delay 44	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 34 0D 0A
569	Sound outputs: Out 3: Delay (ms) = 45	set output 3 audio delay 45	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 35 0D 0A
570	Sound outputs: Out 3: Delay (ms) = 46	set output 3 audio delay 46	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 36 0D 0A
571	Sound outputs: Out 3: Delay (ms) = 47	set output 3 audio delay 47	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 37 0D 0A
572	Sound outputs: Out 3: Delay (ms) = 48	set output 3 audio delay 48	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 38 0D 0A
573	Sound outputs: Out 3: Delay (ms) = 49	set output 3 audio delay 49	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 39 0D 0A
574	Sound outputs: Out 3: Delay (ms) = 50	set output 3 audio delay 50	73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 30 0D 0A
575	Sound outputs: Out 4: Delay (ms) = 0	set output 4 audio delay 0	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 30 0D 0A

576	Sound outputs: Out 4: Delay (ms) = 1	set output 4 audio delay 1	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 0D 0A
577	Sound outputs: Out 4: Delay (ms) = 2	set output 4 audio delay 2	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 0D 0A
578	Sound outputs: Out 4: Delay (ms) = 3	set output 4 audio delay 3	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 0D 0A
579	Sound outputs: Out 4: Delay (ms) = 4	set output 4 audio delay 4	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 0D 0A
580	Sound outputs: Out 4: Delay (ms) = 5	set output 4 audio delay 5	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 0D 0A
581	Sound outputs: Out 4: Delay (ms) = 6	set output 4 audio delay 6	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 36 0D 0A
582	Sound outputs: Out 4: Delay (ms) = 7	set output 4 audio delay 7	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 37 0D 0A
583	Sound outputs: Out 4: Delay (ms) = 8	set output 4 audio delay 8	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 38 0D 0A
584	Sound outputs: Out 4: Delay (ms) = 9	set output 4 audio delay 9	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 39 0D 0A
585	Sound outputs: Out 4: Delay (ms) = 10	set output 4 audio delay 10	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 30 0D 0A
586	Sound outputs: Out 4: Delay (ms) = 11	set output 4 audio delay 11	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 31 0D 0A
587	Sound outputs: Out 4: Delay (ms) = 12	set output 4 audio delay 12	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 32 0D 0A
588	Sound outputs: Out 4: Delay (ms) = 13	set output 4 audio delay 13	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 33 0D 0A
589	Sound outputs: Out 4: Delay (ms) = 14	set output 4 audio delay 14	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 34 0D 0A
590	Sound outputs: Out 4: Delay (ms) = 15	set output 4 audio delay 15	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 35 0D 0A
591	Sound outputs: Out 4: Delay (ms) = 16	set output 4 audio delay 16	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 36 0D 0A
592	Sound outputs: Out 4: Delay (ms) = 17	set output 4 audio delay 17	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 37 0D 0A
593	Sound outputs: Out 4: Delay (ms) = 18	set output 4 audio delay 18	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 38 0D 0A
594	Sound outputs: Out 4: Delay (ms) = 19	set output 4 audio delay 19	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 31 39 0D 0A
595	Sound outputs: Out 4: Delay (ms) = 20	set output 4 audio delay 20	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 30 0D 0A
596	Sound outputs: Out 4: Delay (ms) = 21	set output 4 audio delay 21	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 31 0D 0A
597	Sound outputs: Out 4: Delay (ms) = 22	set output 4 audio delay 22	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 32 0D 0A
598	Sound outputs: Out 4: Delay (ms) = 23	set output 4 audio delay 23	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 33 0D 0A
599	Sound outputs: Out 4: Delay (ms) = 24	set output 4 audio delay 24	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 34 0D 0A

600	Sound outputs: Out 4: Delay (ms) = 25	set output 4 audio delay 25	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 35 0D 0A
601	Sound outputs: Out 4: Delay (ms) = 26	set output 4 audio delay 26	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 36 0D 0A
602	Sound outputs: Out 4: Delay (ms) = 27	set output 4 audio delay 27	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 37 0D 0A
603	Sound outputs: Out 4: Delay (ms) = 28	set output 4 audio delay 28	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 38 0D 0A
604	Sound outputs: Out 4: Delay (ms) = 29	set output 4 audio delay 29	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 32 39 0D 0A
605	Sound outputs: Out 4: Delay (ms) = 30	set output 4 audio delay 30	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 30 0D 0A
606	Sound outputs: Out 4: Delay (ms) = 31	set output 4 audio delay 31	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 31 0D 0A
607	Sound outputs: Out 4: Delay (ms) = 32	set output 4 audio delay 32	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 32 0D 0A
608	Sound outputs: Out 4: Delay (ms) = 33	set output 4 audio delay 33	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 33 0D 0A
609	Sound outputs: Out 4: Delay (ms) = 34	set output 4 audio delay 34	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 34 0D 0A
610	Sound outputs: Out 4: Delay (ms) = 35	set output 4 audio delay 35	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 35 0D 0A
611	Sound outputs: Out 4: Delay (ms) = 36	set output 4 audio delay 36	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 36 0D 0A
612	Sound outputs: Out 4: Delay (ms) = 37	set output 4 audio delay 37	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 37 0D 0A
613	Sound outputs: Out 4: Delay (ms) = 38	set output 4 audio delay 38	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 38 0D 0A
614	Sound outputs: Out 4: Delay (ms) = 39	set output 4 audio delay 39	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 33 39 0D 0A
615	Sound outputs: Out 4: Delay (ms) = 40	set output 4 audio delay 40	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 30 0D 0A
616	Sound outputs: Out 4: Delay (ms) = 41	set output 4 audio delay 41	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 31 0D 0A
617	Sound outputs: Out 4: Delay (ms) = 42	set output 4 audio delay 42	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 32 0D 0A
618	Sound outputs: Out 4: Delay (ms) = 43	set output 4 audio delay 43	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 33 0D 0A
619	Sound outputs: Out 4: Delay (ms) = 44	set output 4 audio delay 44	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 34 0D 0A
620	Sound outputs: Out 4: Delay (ms) = 45	set output 4 audio delay 45	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 35 0D 0A
621	Sound outputs: Out 4: Delay (ms) = 46	set output 4 audio delay 46	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 36 0D 0A
622	Sound outputs: Out 4: Delay (ms) = 47	set output 4 audio delay 47	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 37 0D 0A
623	Sound outputs: Out 4: Delay (ms) = 48	set output 4 audio delay 48	73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 38 0D 0A

624	Sound outputs: Out 4: Delay (ms) = 49	`set output 4 audio delay 49`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 34 39 0D 0A`
625	Sound outputs: Out 4: Delay (ms) = 50	`set output 4 audio delay 50`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 64 65 6C 61 79 20 35 30 0D 0A`
626	Sound EQ: HDMI out 1: EQ = Flat	`set output 1 audio eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
627	Sound EQ: HDMI out 1: EQ = Custom 1	`set output 1 audio eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
628	Sound EQ: HDMI out 1: EQ = Custom 2	`set output 1 audio eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
629	Sound EQ: HDMI out 1: EQ = Custom 3	`set output 1 audio eq preset 4`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 34 0D 0A`
630	Sound EQ: HDMI out 1: EQ = Custom 4	`set output 1 audio eq preset 5`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 35 0D 0A`
631	Sound EQ: HDMI out 1: EQ = Custom 5	`set output 1 audio eq preset 6`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 36 0D 0A`
632	Sound EQ: HDMI/HDBT out 2: EQ = Flat	`set output 2 audio eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
633	Sound EQ: HDMI/HDBT out 2: EQ = Custom 1	`set output 2 audio eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
634	Sound EQ: HDMI/HDBT out 2: EQ = Custom 2	`set output 2 audio eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
635	Sound EQ: HDMI/HDBT out 2: EQ = Custom 3	`set output 2 audio eq preset 4`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 34 0D 0A`
636	Sound EQ: HDMI/HDBT out 2: EQ = Custom 4	`set output 2 audio eq preset 5`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 35 0D 0A`
637	Sound EQ: HDMI/HDBT out 2: EQ = Custom 5	`set output 2 audio eq preset 6`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 36 0D 0A`
638	Sound EQ: Out 3: EQ = Flat	`set output 3 audio eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
639	Sound EQ: Out 3: EQ = Custom 1	`set output 3 audio eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
640	Sound EQ: Out 3: EQ = Custom 2	`set output 3 audio eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
641	Sound EQ: Out 3: EQ = Custom 3	`set output 3 audio eq preset 4`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 34 0D 0A`

642	Sound EQ: Out 3: EQ = Custom 4	`set output 3 audio eq preset 5`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 35 0D 0A`
643	Sound EQ: Out 3: EQ = Custom 5	`set output 3 audio eq preset 6`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 36 0D 0A`
644	Sound EQ: Out 4: EQ = Flat	`set output 4 audio eq preset 1`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 31 0D 0A`
645	Sound EQ: Out 4: EQ = Custom 1	`set output 4 audio eq preset 2`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 32 0D 0A`
646	Sound EQ: Out 4: EQ = Custom 2	`set output 4 audio eq preset 3`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 33 0D 0A`
647	Sound EQ: Out 4: EQ = Custom 3	`set output 4 audio eq preset 4`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 34 0D 0A`
648	Sound EQ: Out 4: EQ = Custom 4	`set output 4 audio eq preset 5`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 35 0D 0A`
649	Sound EQ: Out 4: EQ = Custom 5	`set output 4 audio eq preset 6`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 70 72 65 73 65 74 20 36 0D 0A`
650	Sound EQ: HDMI out 1: Reset the EQ	`set output 1 audio eq reset`	`73 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 20 65 71 20 72 65 73 65 74 0D 0A`
651	Sound EQ: HDMI/HDBT out 2: Reset the EQ	`set output 2 audio eq reset`	`73 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 20 65 71 20 72 65 73 65 74 0D 0A`
652	Sound EQ: Out 3: Reset the EQ	`set output 3 audio eq reset`	`73 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 20 65 71 20 72 65 73 65 74 0D 0A`
653	Sound EQ: Out 4: Reset the EQ	`set output 4 audio eq reset`	`73 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 20 65 71 20 72 65 73 65 74 0D 0A`
654	Receiver: Receiver shows = HDBT in	`set rx input 1`	`73 65 74 20 72 78 20 69 6E 70 75 74 20 31 0D 0A`
655	Receiver: Receiver shows = HDMI in	`set rx input 2`	`73 65 74 20 72 78 20 69 6E 70 75 74 20 32 0D 0A`
656	Receiver: Receiver switches by itself on	`set rx auto switch 1`	`73 65 74 20 72 78 20 61 75 74 6F 20 73 77 69 74 63 68 20 31 0D 0A`
657	Receiver: Receiver switches by itself off	`set rx auto switch 0`	`73 65 74 20 72 78 20 61 75 74 6F 20 73 77 69 74 63 68 20 30 0D 0A`
658	Receiver: Receiver detects a source by = Source 5V	`set rx auto switch mode 1`	`73 65 74 20 72 78 20 61 75 74 6F 20 73 77 69 74 63 68 20 6D 6F 64 65 20 31 0D 0A`
659	Receiver: Receiver detects a source by = Signal	`set rx auto switch mode 2`	`73 65 74 20 72 78 20 61 75 74 6F 20 73 77 69 74 63 68 20 6D 6F 64 65 20 32 0D 0A`
660	Receiver: Receiver USB device ports' 5V = Force off	`set rx usb power 0`	`73 65 74 20 72 78 20 75 73 62 20 70 6F 77 65 72 20 30 0D 0A`
661	Receiver: Receiver USB device ports' 5V = Force on	`set rx usb power 1`	`73 65 74 20 72 78 20 75 73 62 20 70 6F 77 65 72 20 31 0D 0A`
662	Receiver: Receiver USB device ports' 5V = Follow host	`set rx usb power 2`	`73 65 74 20 72 78 20 75 73 62 20 70 6F 77 65 72 20 32 0D 0A`

663	Screen power: Turn the screen on and off by itself on	`set auto power feature 1`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 66 65 61 74 75 72 65 20 31 0D 0A`
664	Screen power: Turn the screen on and off by itself off	`set auto power feature 0`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 66 65 61 74 75 72 65 20 30 0D 0A`
665	Screen power: Turn it off after no source for = 5 sec	`set auto power off timer 1`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 20 31 0D 0A`
666	Screen power: Turn it off after no source for = 10 sec	`set auto power off timer 2`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 20 32 0D 0A`
667	Screen power: Turn it off after no source for = 30 sec	`set auto power off timer 3`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 20 33 0D 0A`
668	Screen power: Turn it off after no source for = 1 min	`set auto power off timer 4`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 20 34 0D 0A`
669	Screen power: Turn it off after no source for = 5 min	`set auto power off timer 5`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 20 35 0D 0A`
670	Screen power: Turn it off after no source for = 10 min	`set auto power off timer 6`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 20 36 0D 0A`
671	Screen power: Turn it on and off with = CEC	`set auto power control 1`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 63 6F 6E 74 72 6F 6C 20 31 0D 0A`
672	Screen power: Turn it on and off with = RS-232	`set auto power control 2`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 63 6F 6E 74 72 6F 6C 20 32 0D 0A`
673	Screen power: Turn it on and off with = CEC and RS-232	`set auto power control 3`	`73 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 63 6F 6E 74 72 6F 6C 20 33 0D 0A`
674	USB: USB switching = Follow video	`set usb switch mode 1`	`73 65 74 20 75 73 62 20 73 77 69 74 63 68 20 6D 6F 64 65 20 31 0D 0A`
675	USB: USB switching = Manual	`set usb switch mode 2`	`73 65 74 20 75 73 62 20 73 77 69 74 63 68 20 6D 6F 64 65 20 32 0D 0A`
676	USB: USB switching = Auto (switch on USB 5V)	`set usb switch mode 3`	`73 65 74 20 75 73 62 20 73 77 69 74 63 68 20 6D 6F 64 65 20 33 0D 0A`
677	USB: USB devices go to = USB-C 1	`set usb manual 1`	`73 65 74 20 75 73 62 20 6D 61 6E 75 61 6C 20 31 0D 0A`
678	USB: USB devices go to = USB-C 2	`set usb manual 2`	`73 65 74 20 75 73 62 20 6D 61 6E 75 61 6C 20 32 0D 0A`
679	USB: USB devices go to = USB host 3	`set usb manual 3`	`73 65 74 20 75 73 62 20 6D 61 6E 75 61 6C 20 33 0D 0A`
680	USB: USB devices go to = USB host 4	`set usb manual 4`	`73 65 74 20 75 73 62 20 6D 61 6E 75 61 6C 20 34 0D 0A`
681	USB: USB device ports' 5V = Force off	`set usb power 0`	`73 65 74 20 75 73 62 20 70 6F 77 65 72 20 30 0D 0A`
682	USB: USB device ports' 5V = Force on	`set usb power 1`	`73 65 74 20 75 73 62 20 70 6F 77 65 72 20 31 0D 0A`
683	USB: USB device ports' 5V = Follow host	`set usb power 2`	`73 65 74 20 75 73 62 20 70 6F 77 65 72 20 32 0D 0A`
684	USB: Laptops on USB-C reach the network = All USB-C inputs	`set UsbcAccessNetwork 0`	`73 65 74 20 55 73 62 63 41 63 63 65 73 73 4E 65 74 77 6F 72 6B 20 30 0D 0A`
685	USB: Laptops on USB-C reach the network = USB-C 1	`set UsbcAccessNetwork 1`	`73 65 74 20 55 73 62 63 41 63 63 65 73 73 4E 65 74 77 6F 72 6B 20 31 0D 0A`
686	USB: Laptops on USB-C reach the network = USB-C 2	`set UsbcAccessNetwork 2`	`73 65 74 20 55 73 62 63 41 63 63 65 73 73 4E 65 74 77 6F 72 6B 20 32 0D 0A`

687	**USB: Laptops on USB-C reach the network = None**	`set UsbcAccessNetwork 3`	`73 65 74 20 55 73 62 63 41 63 63 65 73 73 4E 65 74 77 6F 72 6B 20 33 0D 0A`
688	**Presets: Clear a preset 1**	`set preset clear 1`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 31 0D 0A`
689	**Presets: Clear a preset 2**	`set preset clear 2`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 32 0D 0A`
690	**Presets: Clear a preset 3**	`set preset clear 3`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 33 0D 0A`
691	**Presets: Clear a preset 4**	`set preset clear 4`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 34 0D 0A`
692	**Presets: Clear a preset 5**	`set preset clear 5`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 35 0D 0A`
693	**Presets: Clear a preset 6**	`set preset clear 6`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 36 0D 0A`
694	**Presets: Clear a preset 7**	`set preset clear 7`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 37 0D 0A`
695	**Presets: Clear a preset 8**	`set preset clear 8`	`73 65 74 20 70 72 65 73 65 74 20 63 6C 65 61 72 20 38 0D 0A`
696	**System: Lock the front buttons (on = locked) on**	`set front button 1`	`73 65 74 20 66 72 6F 6E 74 20 62 75 74 74 6F 6E 20 31 0D 0A`
697	**System: Lock the front buttons (on = locked) off**	`set front button 0`	`73 65 74 20 66 72 6F 6E 74 20 62 75 74 74 6F 6E 20 30 0D 0A`
698	**System: Beep on**	`set beep 1`	`73 65 74 20 62 65 65 70 20 31 0D 0A`
699	**System: Beep off**	`set beep 0`	`73 65 74 20 62 65 65 70 20 30 0D 0A`
700	**System: IR remote on**	`set ir 1`	`73 65 74 20 69 72 20 31 0D 0A`
701	**System: IR remote off**	`set ir 0`	`73 65 74 20 69 72 20 30 0D 0A`
702	**System: Fan = Auto**	`set fan speed 0`	`73 65 74 20 66 61 6E 20 73 70 65 65 64 20 30 0D 0A`
703	**System: Fan = 25%**	`set fan speed 1`	`73 65 74 20 66 61 6E 20 73 70 65 65 64 20 31 0D 0A`
704	**System: Fan = 50%**	`set fan speed 2`	`73 65 74 20 66 61 6E 20 73 70 65 65 64 20 32 0D 0A`
705	**System: Fan = 75%**	`set fan speed 3`	`73 65 74 20 66 61 6E 20 73 70 65 65 64 20 33 0D 0A`
706	**System: Fan = 100%**	`set fan speed 4`	`73 65 74 20 66 61 6E 20 73 70 65 65 64 20 34 0D 0A`

4. READING THE UNIT BACK

Send these to read the unit back (on a timer, or after a change).

#	String	Bytes (hex)	The reply gives
1	`get master audio vol`	`67 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 76 6F 6C 0D 0A`	Volume
2	`get master audio mute`	`67 65 74 20 6D 61 73 74 65 72 20 61 75 64 69 6F 20 6D 75 74 65 0D 0A`	Mute the sound

3	`get power`	`67 65 74 20 70 6F 77 65 72 0D 0A`	Power
4	`get rx input`	`67 65 74 20 72 78 20 69 6E 70 75 74 0D 0A`	Receiver shows
5	`get rx auto switch`	`67 65 74 20 72 78 20 61 75 74 6F 20 73 77 69 74 63 68 0D 0A`	Receiver switches by itself
6	`get rx hdmi5v`	`67 65 74 20 72 78 20 68 64 6D 69 35 76 0D 0A`	Something on the receiver's HDMI input
7	`get output auto switch mode`	`67 65 74 20 6F 75 74 70 75 74 20 61 75 74 6F 20 73 77 69 74 63 68 20 6D 6F 64 65 0D 0A`	Detect a new source by
8	`get output main 1 audio`	`67 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 31 20 61 75 64 69 6F 0D 0A`	Plays the sound of
9	`get output main 2 audio`	`67 65 74 20 6F 75 74 70 75 74 20 6D 61 69 6E 20 32 20 61 75 64 69 6F 0D 0A`	Plays the sound of
10	`get output 1 audio`	`67 65 74 20 6F 75 74 70 75 74 20 31 20 61 75 64 69 6F 0D 0A`	Plays
11	`get output 2 audio`	`67 65 74 20 6F 75 74 70 75 74 20 32 20 61 75 64 69 6F 0D 0A`	Plays
12	`get output 3 audio`	`67 65 74 20 6F 75 74 70 75 74 20 33 20 61 75 64 69 6F 0D 0A`	Plays
13	`get output 4 audio`	`67 65 74 20 6F 75 74 70 75 74 20 34 20 61 75 64 69 6F 0D 0A`	Plays
14	`get rx auto switch mode`	`67 65 74 20 72 78 20 61 75 74 6F 20 73 77 69 74 63 68 20 6D 6F 64 65 0D 0A`	Receiver detects a source by
15	`get rx usb power`	`67 65 74 20 72 78 20 75 73 62 20 70 6F 77 65 72 0D 0A`	Receiver USB device ports' 5V
16	`get rx host5v`	`67 65 74 20 72 78 20 68 6F 73 74 35 76 0D 0A`	Something on the receiver's USB host port
17	`get auto power feature`	`67 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 66 65 61 74 75 72 65 0D 0A`	Turn the screen on and off by itself
18	`get auto power off timer`	`67 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 6F 66 66 20 74 69 6D 65 72 0D 0A`	Turn it off after no source for

19	`get auto power control`	`67 65 74 20 61 75 74 6F 20 70 6F 77 65 72 20 63 6F 6E 74 72 6F 6C 0D 0A`	Turn it on and off with
20	`get usb switch mode`	`67 65 74 20 75 73 62 20 73 77 69 74 63 68 20 6D 6F 64 65 0D 0A`	USB switching
21	`get usb switch`	`67 65 74 20 75 73 62 20 73 77 69 74 63 68 0D 0A`	USB devices go to
22	`get usb power`	`67 65 74 20 75 73 62 20 70 6F 77 65 72 0D 0A`	USB device ports' 5V
23	`get UsbcAccessNetwork`	`67 65 74 20 55 73 62 63 41 63 63 65 73 73 4E 65 74 77 6F 72 6B 0D 0A`	Laptops on USB-C reach the network
24	`get front button`	`67 65 74 20 66 72 6F 6E 74 20 62 75 74 74 6F 6E 0D 0A`	Lock the front buttons (on = locked)
25	`get beep`	`67 65 74 20 62 65 65 70 0D 0A`	Beep
26	`get ir`	`67 65 74 20 69 72 0D 0A`	IR remote
27	`get fan speed`	`67 65 74 20 66 61 6E 20 73 70 65 65 64 0D 0A`	Fan
28	`get temp`	`67 65 74 20 74 65 6D 70 0D 0A`	Temperature (°C)
29	`get uptime`	`67 65 74 20 75 70 74 69 6D 65 0D 0A`	Running for (days:hours:min:sec)
30	`get version`	`67 65 74 20 76 65 72 73 69 6F 6E 0D 0A`	Firmware
31	`get ipconfig`	`67 65 74 20 69 70 63 6F 6E 66 69 67 0D 0A`	IP mode, Address, Subnet mask, Gateway, Control port, Telnet port

5. TROUBLESHOOTING

Nothing happens.
Check the unit's IP address and that TCP 8000 is open between the Tesira server and the unit (same network or VLAN, or routed; no firewall in between). Check the line ending is sent after each string.

The unit answers with an error.
The string or its value is not one it takes, or the unit is in standby: turn it on first.